


Key features



Innovative

- Slim high-performance valves in sturdy metal housing
- MPA1 flow rates up to 360 l/min
- MPA2 flow rates up to 700 l/min
- From the individual valve to the valve terminal with multi-pin plug, AS-interface, CPI and fieldbus connections and control block
- Dream team: fieldbus valve terminal suitable for electrical peripherals CPX. This means:

 Forward-looking internal communication system for actuation of the valves and CPX modules
 - Diagnostics down to the individual valve
 - Valves can be actuated with or without (standard) isolated electrical circuits

Versatile

- Modular system offering a range of configuration options
- Expandable up to 128 solenoid coils
- Conversion and expansion possible at a later date
- Further manifold blocks can be assembled using just three screws and sturdy separating seals on metal separator plates
- Integration of innovative function modules possible
- Manual regulators, rotatable pressure gauges
- Proportional pressure regulators
- Additional air supply via additional pressure zones using supply plates
- Wide range of pressures
 -0.9 ... 10 bar
- Wide range of valve functions

Reliable

- Sturdy and durable metal components
- Valves
- Manifold blocks
- Seals
- Fast troubleshooting thanks to LEDs on the valves and diagnostics via fieldbus
- Extensive operating voltage range ±25%
- Ease of servicing through replaceable valves and electronics modules
- Manual override either non-detenting, detenting or secured against unauthorised activation (covered)
- Durable, thanks to tried and tested piston spool valves
- Large and durable labelling system, suitable for barcodes


Easy to mount

- Ready-to-install unit, already assembled and tested
- Lower selection, ordering, installation and commissioning costs
- Secure mounting on wall or H-rail mounting

Subject to change - 2018/05

→ Internet: www.festo.com/catalog/...

Key features



Key features

Valve terminal configurator

Selecting an MPA valve terminal using the online catalogue is quick and easy thanks to the convenient valve terminal configurator provided. This makes it much easier to find the right product. The valve terminals are fully assembled according to your order specifications and are individually tested. This reduces the assembly and installation time to a minimum. The valve terminal MPA is ordered using the order code.


Ordering system for MPA → Internet: mpa Ordering system for CPX → Internet: cpx

2D/3D CAD data


You can request the CAD data for a valve terminal you have configured. To do so, perform the product search as described above. Go to the shopping basket and click on the CAD icon (compass). On the next page you can generate a 3D preview or request another data format of your choice by e-mail.

Online via: → www.festo.com

Online via: → www.festo.com




Key features



Key features

Fieldbus connection via the CPX system




An integrated fieldbus node manages communication with a higher-order PLC. This enables a space-saving pneumatic and electronic solution. Valve terminals with fieldbus interfaces can be configured with up to 16 manifold blocks. In conjunction with MPA1 and 8 solenoid coils per manifold block, up to 128 solenoid coils can thus be actuated. An MPA2 with 4 solenoid coils per manifold block can actuate 64 solenoid coils.

Versions

- PROFIBUS DP
- INTERBUS
- DeviceNet
- CANopen
- CC-Link
- EtherNet/IP
- PROFINET
- POWERLINK
- EtherCAT
- Sercos III
- Front End Controller Remote
- Front End Controller Remote I/O
- Modbus/TCP
- CPX terminal
- → Internet: cpx

Control block connection via the CPX system



Controllers integrated in the Festo valve terminals enable the construction of stand-alone control units to IP65, without control cabinets. Using the slave operation mode, these valve terminals can be used for intelligent pre-processing and are therefore ideal modules for designing decentralised intelligence. In the master operation mode, terminal groups can be designed with many options and functions which can autonomously control a mediumsized machine/system.

CPX terminal

➔ Internet: cpx


📲 - Note

Note possible restrictions for the IP protection class → ATEX conformity declaration

Peripherals overview

Modular pneumatic components

The modular design of the MPA facilitates maximum flexibility right from the planning stage and offers maximum ease of service in operation. The system consists of manifold blocks and valves. The manifold blocks are screwed together and thus form the support system for the valves. They contain the connection ducts for supplying compressed air to and venting from the valve terminal as well as the working lines for the pneumatic drives for each valve. Each manifold block is connected to the next using three screws. Individual terminal sections can be isolated and further manifold blocks inserted by loosening these screws. This ensures that the valve terminal can be rapidly and reliably extended.




Modular electrical peripherals


The manner in which the valves are actuated differs according to whether you are using a multi-pin terminal, fieldbus terminal or individual valve. The MPA with CPX interface is based on the internal bus system of the CPX and uses this serial communication system for all solenoid coils and a range of electrical input and output functions. Serial linking facilitates the following:

- Transmission of switching information
- High valve density
- Compact design
- Position-based diagnostics
- Separate voltage supply for valves
- Flexible conversion without address shifting
- Transmission of status, parameter and diagnostic data
 - ➔ Internet: cpx
- Option of CP interface
- CPX-CEC as stand-alone controller with access via Ethernet and web server





Modularity with electrical peripherals CPX




Peripherals overview

Individual sub-base

- Ordering:
- Using individual part numbers

Individual sub-bases can be equipped with any valve (VMPA... of the corresponding width). The electrical connection is established using a standard 4-pin M8 plug (EN 60947-5-2).




Desc	ription	Brief description	→ Page/Internet
1	Solenoid valve	Width 10 mm, 14 mm, 20 mm	VMPA1
2	Manual override (MO)	Non-detenting/turning with detent, per solenoid coil	VMPA1
3	Coded cover cap	Manual override with non-detenting operation only once cover cap fitted	VMPA1
4	Covered cover cap	Manual override blocked once cover cap fitted	VMPA1
5	Cover cap, manual override detenting	Manual override detenting and operable without tools once cover cap fitted	VMPA1
6	Inscription label holder	Can be pushed onto manual override	VMPA1
7	Sub-base	For individual valve VMPA	VMPA1
8	Fittings and/or silencers	For working ports (2, 4) and air supply/exhaust ports (1, 3, 5)	VMPA1
9	Fittings, silencers or blanking plugs	For pilot air supply/pilot exhaust air (12/14, 82/84) and pressure compensation	VMPA1
10	Electrical connection M8	4-pin	VMPA1

Peripherals overview

Pneumatic components of the valve terminal - Multi-pin plug, AS-interface

- The manifold blocks are either prepared for:
- 2 or 4 single solenoid valves 2 or 4 double solenoid valves
- depending on the size.
- Double solenoid valve positions can be equipped with any valve or a blanking plate.
- Single solenoid valve positions can only be equipped with single solenoid valves.




Peripherals overview

Pneumatic components of the valve terminal	– Multi-pin plug, AS-interface	
Designation	Brief description	→ Page/Internet
1 Electronics module	For connecting MPA1 or MPA2 valves	79
2 Solenoid valve	Width 10 mm	73
3 Coded cover cap	Manual override with non-detenting operation only once cover cap fitted	80
4 Cover cap	Manual override blocked once cover cap fitted	80
5 Cover cap, manual override detenting	Manual override detenting and operable without tools once cover cap fitted	80
6 Inscription label holder	Can be pushed onto manual override	83
7 Blanking plate	For unused valve position (vacant position), width 10 mm	80
8 Mounting	Optional for valve terminal mounting (on supply plate)	83
9 Flat plate silencer	-	-
10 Exhaust plate	For ducted exhaust air	80
11 Regulator plate	Vertical stacking (pressure regulator plate, vertical pressure shut-off plate, vertical supply	74
	plate)	
12 Solenoid valve	Width 20 mm	73
13 Blanking plate	For unused valve position (vacant position), width 20 mm	80
14 H-rail mounting	-	83
15 Right-hand end plate	-	78
16 Separating seal	For manifold block	80
17 Fittings	For working lines	82
18 Inscription label	-	83
19 Manifold block	For two valve locations, width 20 mm	77
20 Fittings	For pneumatic supply plate	82
21 Supply plate	-	80
22 Electrical manifold module	For multi-pin plug connection, for AS-interface	79
23 Manifold block	For four valve locations, width 10 mm	77
24 Electrical interlinking module	For multi-pin plug connection, for AS-Interface, for a sub-base with pneumatic supply plate	79
	(on the left next to the sub-base)	

Peripherals overview

Pneumatic components of the valve terminal - CPI connection, fieldbus

- The manifold blocks are either prepared for:
- 2 or 4 single solenoid valves 2 or 4 double solenoid valves
- depending on the size.
- Double solenoid valve positions can be equipped with any valve or a blanking plate.
- Single solenoid valve positions can only be equipped with single solenoid valves.



Peripherals overview

Pne	umatic components of the valve terminal \cdot	– CPI connection, fieldbus	
Desi	gnation	Brief description	→ Page/Internet
1	Electronics module	-	79
2	Solenoid valve	Width 10 mm	73
3	Coded cover cap	Manual override with non-detenting operation only once cover cap fitted	80
4	Cover cap	Manual override blocked once cover cap fitted	80
5	Cover cap, manual override detenting	Manual override detenting and operable without tools once cover cap fitted	80
6	Inscription label holder	Can be pushed onto manual override	83
7	Blanking plate	For unused valve position (vacant position), width 10 mm	80
8	Electrical manifold module	For fieldbus connection, for proportional pressure regulator	79
9	Mounting	Optional for valve terminal mounting (on supply plate)	83
10	Flat plate silencer	-	-
11	Exhaust plate	For ducted exhaust air	80
12	Mounting	Optional for valve terminal mounting	83
		(on the manifold block of the proportional pressure regulator)	
13	Electrical module	For proportional pressure regulator	79
14	Proportional pressure regulator	-	77
15	Regulator plate	Vertical stacking (pressure regulator plate, vertical pressure shut-off plate, vertical supply plate)	74
16	Solenoid valve	Width 20 mm	73
17	Blanking plate	For unused valve position (vacant position), width 20 mm	80
18	H-rail mounting	-	83
19	Right-hand end plate	-	78
20	Separating seal	For manifold block	80
21	Fittings	For working lines	82
22	Manifold block	For two valve locations, width 20 mm	77
23	Manifold block	For proportional pressure regulator	77
24	Pressure sensor	-	80
25	Fittings	For pneumatic supply plate	82
26	Supply plate	-	80
27	Electrical supply plate	For auxiliary voltage supply for large valve terminals	79
28	Inscription label	-	83
29	Manifold block	For four valve locations, width 10 mm	77

FESTO

.

Peripherals overview

Valve terminal with multi-pin plug connection

Order code:

- 32P-... for the pneumatic components
- 32E-... for the electrical components


MPA valve terminals with multi-pin plug connection can be expanded by up to 24 solenoid coils.

The multi-pin plug connection is designed as a removable 25-pin Sub-D connection to IP65.

- ordering: • 2.5 m
- 5 m
- 10 m

Each can be used for max. 8 or 24 valves.

The cable can be selected when



Designation	Brief description	→ Page/Internet
1 Inscription labels	Large, for multi-pin plug connection	-
2 Flat plate silencer	For pneumatic interface	-
3 Exhaust plate	For ducted exhaust air	80
4 Multi-pin plug connection	For self-assembly	81
5 Multi-pin plug connection	With multi-pin cable	81
6 H-rail mounting	-	83
7 Electrical interface	For multi-pin plug	78

Peripherals overview


Valve terminal with AS-interface connection

Order code:

• 32P-... for the pneumatic components

MPA valve terminals with AS-interface connection can be expanded by up to 8 solenoid coils.

• 52E-... for the electrical components



Des	gnation	Brief description	→ Page/Internet
1	Manifold block	-	78
2	Flat plate silencer	For pneumatic interface	-
3	Exhaust plate	For ducted exhaust air	80
4	Cover	-	-
5	Electrical interface	-	78


Peripherals overview

Valve terminal with CPI connection

Order code:

- 32P-... for the pneumatic components
- 56E-... for the electrical components

MPA valve terminals with CPI connection can be expanded by up to 32 solenoid coils.



D	esignation	Brief description	→ Page/Internet
	1 Flat plate silencer	For pneumatic interface	-
E	2 Exhaust plate	For ducted exhaust air	80
E	3 Electrical interface	-	78
[4 Inscription label	Large for CPI electrical interface	-

Peripherals overview

Valve terminal with fieldbus connection, control block (electrical peripherals CPX)

Order code:


- 32P-... for the pneumatic components
- 50E-... for the electrical components

Valve terminals with fieldbus interfaces can be configured with up to 16 manifold blocks. In conjunction with MPA1 and 8 solenoid coils per manifold block, up to 128 solenoid coils can thus be equipped. An MPA2 with 4 solenoid coils per manifold block can actuate 64 solenoid coils.

Each valve position can be equipped with any valve or a blanking plate. The rules for CPX apply to the equipment that can be used in combination with the electrical peripherals CPX. In general:

- Digital inputs/outputs
- Analogue inputs/outputs
- Parameterisation of inputs and outputs


- Integrated multi-featured diagnostic system
- Preventive maintenance concepts



Designation	Brief description	→ Page/Internet
1 Flat plate silencer	For pneumatic interface	-
2 Exhaust plate	For ducted exhaust air	80
3 CPX modules	-	-
4 Pneumatic interface	For CPX modules	78
5 Inscription label	Large, for pneumatic interface CPX	-
6 H-rail mounting	-	83

Key features – Pneumatic components

Sub-base valve



MPA offers a comprehensive range of valve functions. All valves are equipped with patented sealing system which facilitates efficient sealing, a broad pressure range and long service life. To increase power they have a pneumatic pilot control supplied by pilot air.

Sub-base valves can be quickly replaced since the tubing connectors remain on the manifold block. This design is also particularly flat. Irrespective of the valve function there are sub-base valves with one solenoid coil (single solenoid) or with two solenoid coils (double solenoid or two single solenoid valves in one housing).

Constructional design

Valve replacement


The valves are attached to the metal manifold block using two screws, which means that they can be easily replaced. The mechanical sturdiness of the manifold block guarantees excellent long-term sealing.

Extension

Blanking plates can be replaced by valves at a later date. The dimensions, mounting points and existing pneumatic installations remain unchanged during this process. The valve code (M, MS, MU, J, N, NS, NU, K, KS, KU, H, HS, HU, B, G, E, X, W, D, DS, I) is located on the front of the valve beneath the manual override.

5/2-way val	ve		
Code	Circuit symbol	Width [mm]	Description
Μ		10, 20	 Single solenoid Pneumatic spring return Reverse operation Operating pressure -0.9 +10 bar
MS		10, 20	 Single solenoid Mechanical spring return Reverse operation Operating pressure -0.9 +8 bar
MU		10	 Single solenoid Polymer poppet valve Mechanical spring return Reverse operation Operating pressure -0.9 +10 bar
J	14 4 2 12 14 5 1 3 12	10, 20	 Double solenoid Reverse operation Operating pressure -0.9 +10 bar

Key features – Pneumatic components




Key features – Pneumatic components

5/3-way val	ve		
Code	Circuit symbol	Width [mm]	Description
В	14 W 4 2 W 12 14 84 5 1 3 82 12	10, 20	 Mid-position pressurised¹⁾ Mechanical spring return Reverse operation Operating pressure -0.9 +10 bar
G	14 W 4 2 W 12 14 84 5 1 3 82 12	10, 20	 Mid-position closed¹⁾ Mechanical spring return Reverse operation Operating pressure -0.9 +10 bar
E	14 W 4 2 W 12 14 84 5 1 3 82 12	10, 20	 Mid-position exhausted¹⁾ Mechanical spring return Reverse operation Operating pressure -0.9 +10 bar

If neither solenoid coil is energised, the valve moves to its mid-position by means of spring force. If both coils are energised at the same time, the valve remains in the previously assumed switching position.

3/2-way v	alve		
Code	Circuit symbol	Width	Description
		[mm]	
W	20 4	10,	Single solenoid
		20	Normally open
	│ └╱└ <u>⋛╷</u> ┟╾ ╲ ╽┩╶╤┝╧ <u>┥</u>		 External compressed air supply
	14 84 2 5		 Pneumatic spring return
			Reverse operation
			 Operating pressure –0.9 +10 bar
			Compressed air (-0.9 +10 bar) supplied at working port 2 can
			be switched with both internal and external pilot air supply.
Х	42 ²	10,	Single solenoid
		20	Normally closed
	│ ℤ <u>₽</u> ╗¥╶ҵ┰ ϡ ⋿⊴		 External compressed air supply
	12 82 4 3		Pneumatic spring return
			Reverse operation
			• Operating pressure –0.9 +10 bar
			Compressed air (-0.9 +10 bar) supplied at working port 4 can
			be switched with both internal and external pilot air supply.

Key features – Pneumatic components




- Note

_

A filter must be installed upstream of valves operated in vacuum mode. This prevents any foreign matter in the intake air getting into the valve (e.g. when operating a suction cup).

Key features – Pneumatic components


Vertical stacking



Additional function units can be added to each valve position between the sub-base and the valve. These functions are known as vertical stacking, and enable special function-

ing or control of an individual valve position.


Pressure regulator plate



An adjustable pressure regulator can be installed between the sub-base and the valve in order to control the force of the triggered actuator. This pressure regulator maintains an essentially constant output pressure (secondary side) independent of pressure fluctuations (primary side) and air consumption. Standard version:

- For regulating range up to 6 bar or up to 10 bar
- Without pressure gauge (optional, rotatable, M5 connection with MPA1, cartridge connection with MPA2)
- MPA2: Regulator head with 3 positions (locked, reference position, idle running)
- MPA1: Set using screwdriver

Vertical pressure shut-off plate for MPA1



The vertical pressure shut-off plate can be used to hot swap individual valves without switching off the overall air supply. The working pressure for the individual valve can be switched off manually via the vertical pressure shut-off plate using the actuating element.

Vertical pressure supply plate for MPA2

Key features – Pneumatic components

Vertical stacking

This vertical pressure supply plate enables an individual valve to be supplied with individual operating pressure independently of the operating pressure of the valve terminal. The exhaust and pilot air supply of the valve are still provided via the central connections of the valve terminal.

Non-return valve



The non-return valves prevent the air (back pressure) from exhaust ducts 3 and 5 from entering the solenoid valve, thereby preventing the back pressure from having a disruptive effect on other connected actuators. The non-return valves are integrated into ducts 3 and 5 of the sub-bases designed specifically for this purpose.

Please see the relevant assembly instructions: → www.festo.com/sp This function makes it possible to effectively protect single-acting process valves from the effects of back pressure.

This ensures reliable and feedbackfree switching operations, especially in the case of rapid switching operations.


- Note

- Special sub-bases are available for use with non-return valves.
- Standard sub-bases cannot be retrofitted with non-return valves.
- Pre-assembled sub-bases with integrated non-return valves are available.
- It is not possible to use a nonreturn valve and a fixed restrictor (in the same duct) at the same time.

Key features – Pneumatic components


Vertical stacking

Vertical stacking components, MPA1




- 3 Vertical pressure shut-off plate VMPA1-HS
- 4 Regulator plate VMPA1
- 5 Manifold sub-base

Fixed restrictor for manifold sub-bases MPA1



- 3 Retainer
- 4 Manifold sub-base

FESTO




The fixed restrictor can be used to permanently set the flow rate in ducts 3 and 5 when exhausting air. To be able to screw the restrictor into the subbase, the retainer is first pressed as far as it will go into the exhaust openings on the sub-base. The fixed restrictor can then be screwed in until it is flush with the top of the retainer. The restrictor screw cuts a thread into the retainer as it is screwed in. As the restrictor is being screwed in, two hooks on the underside of the retainer also deform to additionally anchor the retainer in the sub-base.

→ Internet: www.festo.com/catalog/...

Key features – Pneumatic components

Vertical stacking

Non-return valve



- 1 VMPA1 valve
- 2 Assembly tool
- 3 Non-return valve
- 4 Sub-base

Festo non-return valves can only be used in combination with the subbases designed specifically for this purpose.

The non-return valves should be installed according to the specifications using the enclosed assembly tool. Following assembly, the non-return valves cannot be removed.

Please see the relevant assembly instructions: → www.festo.com/sp

For widths 10 mm and 20 mm there are special sub-bases available that facilitate the installation of non-return valves.


- Note

- Special sub-bases are available for use with non-return valves.
- Standard sub-bases cannot be retrofitted with non-return valves.
- Pre-assembled sub-bases with integrated non-return valves are available.
- It is not possible to use a nonreturn valve and a fixed restrictor (in the same duct) at the same time.

Key features – Pneumatic components

Vertical stacking

Mode of operation of the pressure regulator plate (P regulator) for port 1; code: PA, PF



Advantages

- The pressure regulator is not affected by venting, since the pressure is regulated upstream of the valve.
- The pressure regulator can always be adjusted, since the pressure from the valve terminal is always present.


This pressure regulator regulates the pressure upstream of the valve in duct 1. Ducts 2 and 4 thus have the same regulated pressure. During venting, the exhaust flow in the valve is from duct 2 to duct 3 and from duct 4 to duct 5.

Application examples

• An equal working pressure is required at working ports 2 and 4.

This pressure regulator regulates the pressure in duct 2 after the pressure medium flows through the valve. During venting, the exhaust flow in the valve is from duct 2 to duct 3 via • A lower working pressure (e.g. 3 bar) than the operating pressure present at the valve terminal (e.g. 8 bar) is required.

Mode of operation of the pressure regulator plate (B regulator) for port 2; code: PC, PH



Restrictions

The pressure regulator can only be adjusted in switched state (e.g. the valve

is switched to 2 and exhaust flow occurs from 4 to 5).

Application example

the pressure regulator.


The pressure regulator makes it possible to reduce the pressure at port 2 of an individual valve, in con-

trast to the operating pressure of the valve terminal.

Key features – Pneumatic components

Vertical stacking

Mode of operation of the pressure regulator plate (A regulator) for port 4; code: PB, PK



Restrictions


The pressure regulator can only be adjusted in switched state (e.g. the valve is switched to 4 and exhaust flow occurs from 2 to 3).

This pressure regulator regulates the pressure in duct 4 after the pressure medium flows through the valve. During venting, the exhaust flow in the valve is from duct 4 to duct 5 via the pressure regulator.

Application example

If different working pressures are required at ports 4 and 2. The pressure present at port 2 is from duct 1.

Mode of operation of the pressure regulator plate (B regulator, reversible) for port 2, reversible; code: PL, PN



pressure upstream of the valve in duct 3 (the unregulated pressure from duct 1 is in duct 5). The regulated air is then supplied to duct 2. The valve is thus operated in reversible mode.

The reversible B regulator splits the

supply air in duct 1 and regulates the

During venting, the exhaust flow in the valve is from duct 2 to duct 1 and it is reversed into the manifold block via the intermediate plate to duct 3.

that can be operated in reversible

mode.

Application examples

- When instead of the operating pressure of the valve terminal, a different pressure is required in duct 2.
- When fast exhaust venting is required.

Advantages

- Fast cycle times.
- 50% higher exhaust flow rate, as air is not exhausted via the pressure regulator. The load on the pressure regulator is also reduced.
- No quick exhaust valves are required.

• When the pressure regulator must always be adjustable.

• Operating pressure is always

as the pressure is regulated

upstream of the valve, i.e. the

present at the pressure regulator,

regulator can always be adjusted.

Note

- Restrictions
- 2x 3/2-way valves (code N, K, H) are not used, as pressure is present at ports 3 and 5.


Reversible pressure regulator plates

may only be combined with valves

Key features – Pneumatic components

Vertical stacking

Mode of operation of the pressure regulator plate (A regulator, reversible) for port 4, reversible; code: PK, PM



Application examples

• When instead of the operating pressure of the valve terminal, a different pressure is required in duct 4.

Advantages

- Fast cycle times.
- 50% higher exhaust flow rate, as air is not exhausted via the pressure regulator. The load on the pressure regulator is also reduced.
- No quick exhaust valves are required.

- When fast exhaust venting is required.
- When the pressure regulator must always be adjustable.
- Operating pressure is always present at the pressure regulator, as the pressure is regulated upstream of the valve, i.e. the regulator can always be adjusted.

The reversible A regulator splits the working air in duct 1 and supplies the pressure upstream of the valve into duct 5 (the unregulated pressure from duct 1 is in duct 3). The regulated air is then supplied to duct 4. The valve is thus operated in reversible mode. During venting, the exhaust flow in the valve is from duct 4 to duct 1 and it is reversed into the manifold block via the intermediate plate to duct 5.

[≜] - Note

Reversible pressure regulator plates may only be combined with valves

that can be operated in reversible mode.

Restrictions

• 2x 3/2-way valves (code N, K, H) are not used, as pressure is present at ports 3 and 5.

Key features – Pneumatic components

ode	ıl stacking – Pressure regulator pla	Туре	Width Regulating range		ng range	Description
		71	[mm]	up to up to		
				6 bar	10 bar	
ressui	re regulator plate for port 1 (P reg	ulator)				
ł		VMPA1-B8-R1-M5-10	10			Regulates the operating pressure in duct 1
		VMPA1-B8-R1C2-C-10	10	_		upstream of the directional control valve
	<u></u>	VMPA2-B8-R1C2-C-10	20		_	
F	┤┌ ┑┋<u>╺</u>┥ ┽┼┼┼┘││││	VMPA1-B8-R1-M5-06	10			_
•		VMPA1-B8-R1C2-C-06	10	_		
	14 5 1 3 12	VMPA2-B8-R1C2-C-06	20		-	
		VIIII A2-00-K1C2-C-00	20			
	va vagulatav plata far part 2 (D vag	ulatar)				
ressui C	re regulator plate for port 2 (B reg	VMPA1-B8-R2-M5-10	10			Regulates the operating pressure in duct 2
-	4 2 (10			downstream of the directional control valve
		VMPA1-B8-R2C2-C-10		-		uownstream of the directional control ValVe
		VMPA2-B8-R2C2-C-10	20			
Н		VMPA1-B8-R2-M5-06	10			
		VMPA1-B8-R2C2-C-06	10		-	
	14 5 1 3 12	VMPA2-B8-R2C2-C-06	20			
	re regulator plate for port 4 (A reg					_
В	× 4 2	VMPA1-B8-R3-M5-10	10			Regulates the operating pressure in duct 4
		VMPA1-B8-R3C2-C-10	10	-	•	downstream of the directional control valve
		VMPA2-B8-R3C2-C-10	20			
G	┤╷┌┼╭╆═╡┭┼┼┘╎╎╎╎╎	VMPA1-B8-R3-M5-06	10			_
		VMPA1-B8-R3C2-C-06	10	_	_	
	14 5 1 3 12	VMPA2-B8-R3C2-C-06	20	-		
ressu	re regulator plate for port 2, rever	sible (B regulator)				
Ľ		VMPA2-B8-R6C2-C-10	20			Reversible pressure regulator to port 2
				-		
					_	
'N	┤║║╙╎┼┾┶╧┑╢	VMPA2-B8-R6C2-C-06	20			-
IN		VIVIFA2-D0-K0C2-C-00	20			
	14 5 1 3 12			-	-	
recou	re regulator plate for port 4, rever	sible (A regulator)				
K		VMPA2-B8-R7C2-C-10	20			Reversible pressure regulator to port 4
••			20			
	2			-		
M		VMPA2-B8-R7C2-C-06	20			
					-	

Key features – Pneumatic components

Proportional pressure regulator


The purpose of the proportional pressure regulator VPPM-6TA-... is to regulate a pressure proportionally to a specified setpoint value. To this end, an integrated pressure sensor records the pressure at the working line and compares this value against the setpoint value. If there is a deviation between the nominal and actual values, the valve regulates the output pressure until it reaches the setpoint value. The proportional pressure regulator has an additional supply connection to achieve the constant pressure supply required for high control quality. The proportional pressure regulator can be configured via the PLC or onsite via the handheld device (CPX-MMI) from Festo.

- Note

Output pressure is maintained unregulated if the power supply cable is interrupted.

Proportional pressure reg	gulator				
Graphical symbol	Code	Туре	Full-scale linearity error [%]	Supply pressure 1 [bar]	Pressure regulation range [bar]
	QA	VPPM-6TA-L-1-F-0L2H	2	0 4	0,02 2
	QB	VPPM-6TA-L-1-F-0L6H	2	0 8	0,06 6
	QC	VPPM-6TA-L-1-F-0L10H	2	0 11	0,1 10
\land \checkmark $>$	QD	VPPM-6TA-L-1-F-0L2H-S1	1	0 4	0,02 2
	QE	VPPM-6TA-L-1-F-0L6H-S1	1	0 8	0,06 6
	QF	VPPM-6TA-L-1-F-0L10H-S1	1	0 11	0,1 10
	QG	VPPM-8TA-L-1-F-0L2H-C1	2	0 4	0,02 2
\checkmark	QH	VPPM-8TA-L-1-F-0L6H-C1	2	0 8	0,06 6
	QK	VPPM-8TA-L-1-F-0L10H-C1	2	0 11	0,1 10
	QL	VPPM-8TA-L-1-F-0L2H-S1C1	1	0 4	0,02 2
	QM	VPPM-8TA-L-1-F-0L6H-S1C1	1	0 8	0,06 6
	QN	VPPM-8TA-L-1-F-0L10H-S1C1	1	0 11	0,1 10

Key features – Pneumatic components




Layout

The figure shows a closed-loop control circuit. The reference variable w initially acts on a comparator. The measuring device sends the value of the controlled variable x (actual value, e.g. 3 bar) to the comparator as a feedback signal r. The closed-loop control element detects the system deviation e and actuates the final control element. The output of the final control element acts on the controlled system. The closed-loop control element thus attempts to compensate for the difference between the reference variable w and the controlled variable x by using the final control element.

Method of operation

This process runs continuously so changes in the reference variable are always detected. However, a system deviation will also appear if the reference variable is constant but the controlled variable changes. This happens when the flow through the valve changes in response to a switching action, a cylinder movement or a change in load. The disturbance variable z will also cause a system deviation. An example of this is when the pressure drops in the air supply. The disturbance variable z acts on the controlled variable x unintentionally. In all cases, the regulator attempts to readjust the controlled variable x to the reference variable w.



Cascade control

Unlike conventional direct-acting regulators, with multi-sensor control several control circuits are nested inside each other. The overall controlled system is divided into smaller subcontrolled circuits that are easier to control for the specific task.


Control precision

Multi-sensor control significantly improves control precision and dynamic response in comparison with singleacting regulators.

Key features – Pneumatic components

Terms related to the proportional-pressure regulator

Hysteresis



There is always a linear relationship within a certain tolerance between the setpoint value entered and the pressure output. Nevertheless it makes a difference whether the setpoint value is entered as rising or falling. The difference between the maximum deviations is referred to as hysteresis.

The response sensitivity of the device

The smallest setpoint value difference

that results in a change in the output

pressure is referred to as the response


determines how sensitively one can

change, i.e. adjust, a pressure.

sensitivity.

In this case, 0.01 bar.


Linearity error




Repetition accuracy (reproducibility)



A perfectly linear progression of the control characteristic of the output pressure is theoretical. The maximum percentage deviation from this theoretical control characteristic is referred to as the linearity error. The percentage value refers to the maximum output pressure (full scale).



Zero point suppression



In practice there exists the possibility of residual voltage or residual current at the setpoint input of the VPPM via the setpoint generator. Zero point suppression is used so that the valve is reliably vented at a setpoint value of zero. The repetition accuracy is the margin within which the fluid output variables are scattered when the same electrical input signal coming from the same direction is repeatedly adjusted. The repetition accuracy is expressed as a percentage of the maximum fluid output signal.

Key features - Pneumatic components

Blanking plate




Plate without valve function for reserving valve positions on a valve terminal.

The valve terminal MPA can be sup-

plied with air at one or more points.

This ensures that the valve terminal

will always have an adequate air sup-

ply and exhaust, even with large-scale

The main supply to the valve terminal

When there is a need for an increase

in air supply, multiple supply plates

Exhausting is either via integrated flat

The individual compressed air supply of a single valve with a width of 20 mm can be realised using the vertical pressure supply plate

The air to be exhausted can be ducted using the right-hand end plate with port 82/84 (VMPA-ERP-G).

can additionally be provided.

expansions.

VMPA2-VSP-

Valves and blanking plates are attached to the manifold block using two screws.

is located on the pneumatic interface, which links the electrical and the

pneumatic parts. Additional provision

is made for a number of supply plates.

Exhausting is either via integrated flat

plate silencers or common lines for

In the case of ducted exhaust air, at


least one additional supply plate is

ducted exhaust air.

Valve function					
Code	Circuit symbol	Width	Description		
		[mm]			
L	-	10	For valve terminal only:		
		20	Blanking plate for vacant valve position		

Compressed air supply and exhaust


Pneumatics interface



Supply plate



Vertical pressure supply plate



Right-hand end plate (VMPA-ERP-G)



Pilot air supply

The port for the main pneumatic supply is located on the pneumatic interface.

The ports differ for the following types of pilot air supply:

- Internal
- External

Internal pilot air supply

Internal pilot air supply can be selected if the required working pressure is between 3 and 8 bar. The pilot air supply is then branched from the compressed air supply 1 in the pneumatic interface using an internal connection. Port 12/14 is sealed with a blanking plug.

External pilot air supply

If the supply pressure is less than 3 bar or greater than 8 bar, you must operate your MPA valve terminal with external pilot air supply. In this case the pilot air is additionally supplied via port 12/14 on the pneumatic interface.

- - Note

If a gradual pressure build-up in the system using a soft-start valve is chosen, an external pilot air supply should be connected so that the control pressure applied during switch-on is already very high.

FESTO

required, which is used to vent the exhaust air from the pilot air supply (port 82/84) (when using a right-hand end plate, without port 82/84).

plate silencers or common lines for

These exhausts are located on the

pneumatic interface as well as on the

supply plates and on the right-hand

ducted exhaust air.

end plate (VMPA-ERP-G).

→ Internet: www.festo.com/catalog/...

Key features – Pneumatic components

Comp Code	ressed air supply and pilot air and pilot	supply		Notes		
Coue	Type of compressed air supply	and nilot air sunnly		Notes		
	Pneumatic interface	Supply plate	Right-hand end plate			
S	3/5 82/84 12/14 1 01	3/5 3/5 82/84 82/84 1 1 1		 Internal pilot air supply, flat plate silencer Pilot air supply is branched internally from port 1 in the pneumatic interface Exhaust port 3/5 and pilot exhaust port 82/84 via flat plate silencer For operating pressure in the range 3 8 bar 		
T	3/5 82/84 12/14 12/14 0 0 1	3/5 3/5 82/84 82/84 1 1 1 1 1		 External pilot air supply, flat plate silencer Pilot air supply between 3 and 8 bar is connected to port 12/14 Exhaust port 3/5 and pilot exhaust port 82/84 via flat plate silencer For operating pressure in the range –0.9 10 bar (suitable for vacuum) 		
V	3/5 82/84 • 12/14 1	3/5 82/84 1 0 1 0 1		 Internal pilot air supply, ducted exhaust air Pilot air supply is branched internally from port 1 in the pneumatic interface Exhaust port 3/5: connection to pneumatic interface and supply plate Pilot exhaust port 82/84: connection to supply plate only For operating pressure in the range 3 8 bar 		
Х	3/5 82/84 12/14 12/14 0 0 1	3/5 82/84 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 5 1 1 1 1 1 1 1 1 1 1 1 1 1		 External pilot air supply, ducted exhaust air Pilot air supply (3 8 bar) is connected at port 12/14 Exhaust port 3/5: connection to pneumatic interface and supply plate Pilot exhaust port 82/84: connection to supply plate only For operating pressure in the range -0.9 10 bar (suitable for vacuum) 		
Y	3/5 82/84 12/14	3/5 82/84 1 0 1 0 1 1	82/84	 Internal pilot air supply, ducted exhaust air via right-hand end plate Pilot air supply is branched internally from port 1 in the pneumatic interface Exhaust port 3/5: connection to pneumatic interface and supply plate Pilot exhaust air 82/84 ducted via right-hand end plate (VMPA-EPR-G) For operating pressure in the range 3 8 bar 		
Z	3/5 3/5 3/5 3/2 12/14 1 12/14 0 0 1	3/5 82/84 1 82/84 1 0 1	82/84	 External pilot air supply, ducted exhaust air via right-hand end plate Pilot air supply (3 8 bar) is connected at port 12/14 Exhaust port 3/5: connection to pneumatic interface and supply plate Pilot exhaust air 82/84 ducted via right-hand end plate (VMPA-EPR-G) For operating pressure in the range -0.9 10 bar (suitable for vacuum) 		

Pneumatic interface

Pneun	Pneumatic interface				
Code	Code Pneumatic interface design variants Graphical symbol Type		Notes		
Μ		VMPAEPL	 Used together with compressed air supply S, T, V, X The pilot exhaust air must be vented at least at one supply plate when using V or X. In the case of multiple supply plates, the port 82/84 is open on the last supply plate ex-works 		



Key features – Pneumatic components

Supply plate

Supply plate

Additional supply plates can be used for larger terminals or to create additional pressure zones.

If several valves are to be operated simultaneously at full flow rate, it is recommended that a supply plate be positioned after every 8 valves (MPA1), or 4 valves (MPA2). Supply plates can be configured at any point upstream or downstream of sub-bases. This applies to the

- following interfaces: • MPA with CPX
- MPA with multi-pin plug connection
- MPA with AS-interface connection
- MPA with CPI connection

MPA with ducted exhaust air

When using a right-hand end plate without port 82/84, it is essential that a supply plate for ducted exhaust air is used. Alternatively, an end plate with port 82/84 (VMPA-EPR-G) can be used for ducted exhaust air. In this case, no supply plate is required. Supply plates contain the following ports:

- Compressed air supply (1)
- Venting of the pilot air supply (82/84) and pressure compensation
- Exhaust air (3/5)

Depending on your order, the exhaust ducts are either ducted or vented via the flat plate silencer.

The supply plate is configured using the code letter U if no directly adjoining separating seal is required. If a separating seal (S, T or R) is selected to the direct right or left of the supply plate, then the code letter V or W identifies the position of the lefthand or right-hand separating seal. The code for the separating seal (S, T or R) is placed in front of the code for the supply plate (V or W).

	Supply plate							
Code ¹⁾	Graphical symbol	Туре	Notes					
U		VMPA1SP	Supply plate without separating seal (no R, S or T selected)					
V		VMPA1SP	Supply plate with separating seal on left, if R, S or T selected					
W		VMPA1SP	Supply plate with separating seal on right, if R, S or T selected					

1) The supply plate is equipped with silencer or exhaust plate depending on the code for the air supply S, T, V, X.

Key features – Electrical components

Electrical supply plate

Additional electrical supply plates can be used for larger terminals. This enables up to 64 valve positions/128 solenoid coils to be supplied.

MPA with CPX

Electrical supply plates can be configured at any point upstream or downstream of sub-bases. An electrical supply plate is required after 8 valve sub-bases.

MPA with CPI connection

Electrical supply plates can be configured at any point upstream or downstream of manifold blocks. An electrical supply plate is required after 8 valve sub-bases.

- Note

Max. 24 of 32 MPA1 coils or 12 of 16 MPA2 coils can be switched on at the same time in the case of an MPA with CPI connection.

Note

Please note that only electrical modules with isolated electrical circuits are permissible to the right of the electrical supply plate. The electrical supply plate must not be installed directly to the left of a pneumatic supply plate (type VMPA1-FB-SP...).


Electrical	Electrical supply plate					
Code	Graphical symbol	Туре	Notes			
L	and the second s	VMPA-FB-SP-V-SP	Electrical supply plate with M18 plug connection, 3-pin			
		VMPA-FB-SP-7/8-V-5POL	Electrical supply plate with 7/8" plug connection, 5-pin			
	a line	VMPA-FB-SP-7/8-V-4POL	Electrical supply plate with 7/8" plug connection, 4-pin			

Pin allocation for power supply						
	Pin	Allocation				
Pin allocation for M18	Pin allocation for M18					
2	2	24 V DC valves				
$\frac{4}{4}$	3	0 V DC				
4×1×3	4	FE				
	1					
Pin allocation for 7/8", 5-pin						
2 1	1	0 V DC valves				
3 (+ +)	2	n.c.				
	3	FE (leading)				
	4	n.c.				
د 4 ا	5	24 V DC valves				
Pin allocation for 7/8", 4-pin						
	А	n.c.				
$\begin{pmatrix} + \\ + \end{pmatrix}$	В	24 V DC valves				
	С	FE				
B	D	0 V DC valves (leading)				

Key features – Pneumatic components

Creation of pressure zones and separation of exhaust air

If different work pressures are required, MPA offers various possibilities for building up pressure zones. Depending on the electrical interface up to 16 pressure zones are possible. A pressure zone is created by isolating the internal supply ducts between the manifold blocks using an appropriate separating seal or using a separator that is permanently integrated in the manifold block (code I or code III). Compressed air is supplied and vented via a supply plate. The position of the supply plates and separating seals can be freely selected with the valve terminal MPA. Separating seals are integrated exworks as per your order. Separating seals can be distinguished through their coding, even when the valve terminal is assembled.



FESTO

- Note

The following must be taken into consideration for subsequent expansion or conversions: Different separating seals are required for operating with ducted exhaust air and operation with flat plate silencers.

Creating pressure zones						
Code			Separating seal for operating with ducted exhaust air		Notes	
	Pictorial examples	Coding	Pictorial examples	Coding		
-	VMPADPU		VMPADP	\square	No duct separation	
Т	VMPADPU-P		VMPADP-P		Duct 1 separate	
S	VMPADPU-PRS		VMPADP-PRS	\square	Duct 1 and 3/5 separate	
R	VMPADPU-RS		VMPADP-RS		Duct 3/5 separate	

Key features – Pneumatic components

Creating p	Creating pressure zones						
Code	Manifold block with duct separation for operating with flat plate silencer or with ducted	l exhaust air	Notes				
	Pictorial examples	Coding					
I		_	Duct 1 separate				
111		-	Duct 1 and 3/5 separate				

∎ - Ν	ote
-------	-----

â

The duct separation cannot be subsequently removed and is integrated in the centre of the manifold block:


- With width 10 mm between valves 2 and 3
- With width 20 mm between valves 1 and 2

Key features – Pneumatic components

Examples: Compressed air supply and pilot air supply

Internal pilot air supply, flat plate silencer Pneumatic air supply to the valve terminal: code S


The diagram opposite shows an example of the configuration and connection of the air supply with internal pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multi-pin plug) as appropriate is tightly sealed. Ports 3/5 and 82/84 are vented via the flat plate silencers. Port 82/84 is tightly sealed. Separating seals can be used optionally to create pressure zones.



External pilot air supply, flat plate silencer Pneumatic air supply to the valve

terminal: code T

The diagram opposite shows an example of the configuration and connection of the compressed air supply with external pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multi-pin plug) as appropriate is equipped with a threaded connector for this purpose. Ports 3/5 and 82/84 are vented via the flat plate silencers. Port 82/84 is tightly sealed. Separating seals can be used optionally to create pressure zones.




Key features – Pneumatic components

Examples: Compressed air supply and pilot air supply

Internal pilot air supply, ducted exhaust air Pneumatic air supply to the valve terminal: code V


The diagram opposite shows an example of the configuration and connection of the compressed air supply with internal pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multi-pin plug) as appropriate is tightly sealed. Exhaust ports 3/5 and 82/84 are vented via the appropriate connections. Separating seals can be used optionally to create pressure zones.



External pilot air supply, ducted exhaust air Pneumatic supply to the valve

terminal: code X

The diagram opposite shows an example of the configuration and connection of the compressed air supply with external pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multi-pin plug) as appropriate is equipped with a threaded connector for this purpose. Exhaust ports 3/5 and 82/84 are vented via the appropriate connections. Separating seals can be used optionally to create pressure zones.




Key features – Pneumatic components

Examples: compressed air supply and pilot air supply

Internal pilot air supply, ducted exhaust air 82/84 via right-hand end plate

Pneumatic supply to the valve terminal: code Y


The illustration on the right shows an example of the configuration and connection of the compressed air supply in the case of internal pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multipin plug) is tightly sealed. The exhaust port 3/5 is vented via the corresponding ports. The exhaust air from port 82/84 is ducted via the right-hand end plate via the right-hand end plate (VMPA-EPR-G). In this case, there is no need for a supply module for expelling the ducted exhaust air 82/84. Separating seals can be used optionally to create pressure zones.



External pilot air supply, ducted exhaust air 82/84 via right-hand end plate

Pneumatic supply to the valve terminal: code Z


The illustration on the right shows an example of the configuration and connection of the compressed air supply in the case of external pilot air supply. Port 12/14 on the pneumatic interface or the electrical interface (multipin plug) is equipped with a threaded connector for this purpose. The exhaust port 3/5 is vented via the corresponding ports. The exhaust air from port 82/84 is ducted via the right-hand end plate via the righthand end plate (VMPA-EPR-G). In this case, there is no need for a supply module for expelling the ducted exhaust air 82/84. Separating seals can be used optionally to create pressure zones.



Key features – Pneumatic components


Examples: Creating pressure zones

MPA with CPX terminal connection The diagram shows an example of the configuration and connection of three pressure zones using separating seals – with external pilot air supply.



MPA with multi-pin plug connection

The diagram shows an example of the configuration and connection of the pressure zones – with external pilot air supply.






Key features – Pneumatic components

Examples: Creating pressure zones

Manifold block with pressure zone separation in duct 1

Another way of creating pressure zones is to use manifold blocks with pressure zone separation. The diagram opposite shows the version with pressure zone separation in duct 1.




Manifold block with pressure zone separation in duct 1 and duct 3/5

The diagram opposite shows the Zone 2 Zone 1 version with pressure zone separation in duct 1 and duct 3/5. 87/8/ Pilot air supply P_1 P₂ 6

Key features – Pneumatic components

Manifold block



MPA is based on a modular system consisting of manifold blocks and valves. The manifold blocks are screwed together and thus form the support system for the valves. They contain the connection ducts for supplying compressed air to and venting from the valve terminal as well as the working lines for the pneumatic drives for each valve. Each manifold block is connected to the next using three screws. Individual terminal sections can be isolated and further manifold blocks inserted by loosening these screws. This ensures that the valve terminal can be rapidly and reliably extended.

Manifol	d block versions				
Code	Graphical symbol	Туре	Width [mm]	Number of valve positions (solenoid coils)	Notes
Manifol	d block for multi-pin plug/fieldbu	is connection			
A, C ¹⁾		VMPA1-FB-AP-4-1	10	4 (8/4 ¹⁾)	Working lines (2, 4) on the manifold block
AI, CI ¹⁾		VMPA1-FB-AP-4-1-T1			 Connection sizes MPA1: M7, QS4, QS6 Code & Constration in duct 1 in
AIII, CIII ¹⁾		VMPA1-FB-AP-4-1-S1			 Code I: Separation in duct 1 in the manifold block Code III: Separation in duct 1 and duct 3/5 in the manifold block
B, D ¹⁾		VMPA2-FB-AP-2-1	20	2 (4/2 ¹⁾)	Working lines (2, 4) on the manifold block
BI, DI ¹⁾		VMPA2-FB-AP-2-1-TO			 Connection sizes MPA2: G¹/₈, QS6, QS8 Code I: Separation in duct 1 in
BIII, DIII ¹⁾		VMPA2-FB-AP-2-1-SO			 the manifold block Code III: Separation in duct 1 and duct 3/5 in the manifold block

1) Only possible with multi-pin plug connection


- Note

More information about individual sub-bases can be found at: → VMPA1



Key features – Pneumatic components

Pressure sensor



The pressure sensor indicates whether the applied pressure exceeds, adheres to or falls below the setpoint value using three LEDs. An additional LED indicates common errors (limit exceeded or fallen below).

The limits for pressure monitoring are set by means of parameter settings. You can parameterise the pressure sensor plate via the PLC or the handheld device (CPXMMI) from Festo. Alternatively the pressure in the exhaust duct (3/5) and the process pressure (external) can be measured. Pressure measurement in the exhaust duct is used for monitoring the operating pressure during reversible operation (supply to (3/5)).

Pressur	Pressure sensor versions							
Code	Graphical symbol	Туре	Application					
PE		VMPA-FB-PS-1	Monitoring the operating pressure in duct 1					
PF		VMPA-FB-PS-3/5	Monitoring the pressure in exhaust ducts 3 and 5 (monitoring the venting performance or monitoring pressure in the case of reversible valve terminals)					
PG		VMPA-FB-PS-P1	Monitoring an external process pressure					

Key features – Pneumatic components

Code	Graphical symbol	Туре	Width	Number of valve positions	Notes
couc	Shapinear Symbol	1,000	[mm]	(solenoid coils)	
lactroni	cs module for multi-pin plug (I		[]		
A, B, C, D		VMPA1-MPM-EMM-8	10	4 (8)	Each solenoid coil must be assigned
ң, Б, С, Б		VMPA1-MPM-EMM-4	10	4 (8)	to a specific pin of the multi-pin
		VMPA1-MPM-EMM-4		4 (4)	plug in order for the valve to be
					actuated. Regardless of the blank-
					ing plates or valves used, valve
		VMPA2-MPM-EMM-4	20	2 (4)	positions occupy
		VMPA2-MPM-EMM-2		2 (2)	• 1 address for actuation of 1 coil
					 2 addresses for actuation of
	a starter and a starter and a starter a starte				2 coils
					2 0013
lectroni	cs module for fieldbus with sta	andard diagnostics			
A, B, H		VMPAFB-EMS	10	4 (8)	The electronics module contains the
ч, D, П		VMPAFB-EMG	10	+ (0)	serial communication system and
					facilitates:
					Transmission of switching
					information
					Actuation of up to 8 solenoid
					coils
					 Position-based diagnostics
					 Separate voltage supply for
					valves
		VMPAFB-EMS	20	2 (4)	Transmission of status,
		VMPAFB-EMG			parameter and diagnostic data
					There are different versions:
					Without isolated electrical circui
					(VMPAFB-EMS)
					With isolated electrical circuit
					(VMPAFB-EMG)
					Diagnostic function:
					• Error: Load voltage of the valves
	-				-
lectroni	cs module for fieldbus with ext	tended diagnostic function			
A, B, H	ন্দ্রণী	VMPAFB-EMSD2	10	4 (8)	The electronics module with
	MIL	VMPAFB-EMGD2			extended diagnostic function
					contains the same functions as the
					electronics module with standard
	-				diagnostics. The diagnostic func-
		VMPAFB-EMSD2	20	2 (4)	tion, however, has been extended:
		VMPAFB-EMSD2 VMPAFB-EMGD2	20	2 (4)	• Error: Load voltage of the valves
		VINIFAFD-EINGU2			• Error: Wire break (open load)
					• Error: Short circuit in load voltag
					of valves

- 🗍 - Note

- Multi-pin plug with modular linking
- Manifold blocks MPA1 and MPA2 can be combined as required
- Positive or negative switching actuation is possible (mixed operation is not permitted)
- Double solenoid valves cannot be mounted on single solenoid electronics modules
- Single solenoid valves can be mounted on double solenoid electronics modules



Key features – Pneumatic components

Ports fo	or supply and exhaust						
Code		Port		Designation	Code L Large plug connector	Code K Small plug connector	Code D Thread for supply
S		Internal	pilot air supply, silencer				
		1	Supply air/ vacuum supply	Push-in fitting	QS-G1/4-10-I	QS-G1⁄4-8-I	G1⁄4
		3/5	Exhaust air	Flat plate silencer	-	-	-
		12/14	Pilot air supply	-	-	-	-
		82/84	Pilot exhaust air	Flat plate silencer	-	-	-
			Pressure compensation	Vents into the atmosph	ere via silencer	,	L.
Т		Externa	l pilot air supply, silencer				
		1	Supply air/ vacuum supply	Push-in fitting	QS-G1⁄4-10-I	QS-G1⁄4-8-I	G1⁄4
		3/5	Exhaust air	Flat plate silencer	-	-	-
		12/14	Pilot air supply	Push-in fitting	QSM-M7-6-I	QSM-M7-6-I	M7
		82/84	Pilot exhaust air	Flat plate silencer	-	-	-
			Pressure compensation	Vents into the atmosph	ere via silencer		
V			pilot air supply, ducted e				
		1	Supply air/ vacuum supply	Push-in fitting	QS-G ¹ /4-10-I	QS-G1⁄4-8-I	G1⁄4
		3/5	Exhaust air	Push-in fitting	QS-10	QS-10	QS-10
		12/14	Pilot air supply	-	-	-	-
		82/84	Pilot exhaust air	Push-in fitting	QSM-M7-6-I	QSM-M7-6-I	M7
			Pressure compensation	Vents into duct 82/84			
	-	F (
Х			l pilot air supply, ducted e		05 61/ 401	05 61/ 01	C1/
		1	Supply air/ vacuum supply	Push-in fitting	QS-G1⁄4-10-I	QS-G1⁄4-8-I	G1⁄4
		3/5	Exhaust air	Push-in fitting	QS-10	QS-10	QS-10
		12/14	Pilot air supply	Push-in fitting	QSM-M7-6-I	QSM-M7-6-I	M7
		82/84	Pilot exhaust air	Push-in fitting	QSM-M7-6-I	QSM-M7-6-I	M7
			Pressure compensation	Vents into duct 82/84			
Y			pilot air supply, ducted e	1			C1 (
		1	Air/vacuum supply	Push-in fitting	QS-G1/4-10-I	QS-G1/4-8-I	G1/4
		3/5	Exhaust air	Push-in fitting	QS-10	QS-10	QS-10
		12/14	Pilot air supply	- Duch in fitting	-	-	-
		82/84	Pilot exhaust air	Push-in fitting	QSM-M5-3-I	QSM-M5-3-I	M5
			Pressure compensa- tion	Exhausts into duct 82/8	34		
Z		Extorna	l pilot air supply, ducted e	what sirvis right hand	and plate (/MDA EDI	2-6)	
2			Air/vacuum supply	Push-in fitting	QS-G ¹ /4-10-I	QS-G1/4-8-I	G1⁄4
		1 3/5	Exhaust air	Push-in fitting	QS-G44-10-1 QS-10	QS-01/4-8-1 QS-10	QS-10
				Push-in fitting			
		12/14 82/84	Pilot air supply Pilot exhaust air	Push-in fitting	QSM-M7-6-I QSM-M5-3-I	QSM-M7-6-I QSM-M5-3-I	M7 M5
		10//04	E IIUL EXHAUSI AII	1 EUSH-111 1111112	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	

Key features – Assembly

Valve terminal assembly

Sturdy terminal assembly thanks to:


Wall mounting - Fieldbus connection

- Four through-holes for wall mounting
- Additional mounting brackets
- H-rail mounting

📲 - Note

When wall-mounting MPA valve terminals with more than 4 manifold blocks, use additional mounting brackets of the type VMPA-BG-RW to

Wall mounting - Multi-pin plug connection, AS-interface and CPI connection



The MPA valve terminal is screwed onto the mounting surface using four M4 or M6 screws. The mounting holes are on the pneumatic interface plates. and on the right-hand end plate.

There are also optional mounting

brackets available.

terminal. The mounting brackets can


be mounted on the pneumatic supply

prevent damage to the valve

The MPA valve terminal is screwed onto the mounting surface using six M4 or M6 screws. The mounting holes are on the left-hand end plate (CPX) and on the right-hand end plate MPA.

The pneumatic interface also provides further mounting holes as well as optional mounting brackets.

H-rail mounting



The MPA valve terminal is attached to the H-rail (see arrow A). The terminal is then swivelled around the H-rail and secured in place with the clamping component (see arrow B). For H-rail mounting of the valve terminal you will need the following MPA mounting kit:

- With multi-pin plug: CPA-BG-NRH
- With fieldbus: CPX-CPA-BG-NRH This enables mounting of the valve terminal on a H-rail to EN 60715.

- Note

More information about assembly of solenoid valves on individual sub-bases can be found at: → VMPA1

Key features - Display and operation

Display and operation

Each solenoid coil is allocated an LED that indicates its signal status.

- Indicator 12 shows the signal status of the coil for output 2
- Indicator 14 shows the signal status of the coil for output 4

Manual override

The manual override (MO) enables the valve to be actuated when not electrically activated or energised. The valve is switched by pushing the manual override. The set switching status can also be locked by turning the manual override (code R).


Alternatives:

- The cover cap (code N or as an accessory) prevents the manual override from being locked. The manual override can then only be activated by pushing it.
- The cover cap (code V or as an


accessory) can prevent the manual override from being accidentally activated.

FESTO

• The cover cap (code Y or as an accessory) can be used to operate the manual override in detenting mode without additional tools.



Electrical connection and display components on the AS-interface




- 1 M12 socket for AS-interface bus and additional supply (AS-i Out)
- 2 M12 plug for AS-interface bus and additional supply (AS-i In)
- 3 Earth terminal
- 4 Status LEDs for inputs
- 5 Status LEDs for AS-interface
- 6 Diagnostic LEDs for valves

- Note A manually actuated valve (manual

override) cannot be reset electrically. Conversely, an electrically actuated valve cannot be reset using the mechanical manual override.

Key features - Display and operation


Manual override (MO)



- 1 Press in the stem of the MO with a pointed object or screwdriver. Pilot valve switches and actuates the main valve.
- Remove the pointed object or 2 screwdriver.
 - Spring force pushes the stem of the MO back.

Pilot valve returns to its normal position as does the single solenoid main valve (not the case with double solenoid valve code J).

MO with lock (detenting)



MO with lock - Assembly


1 Press in the stem of the MO with a pointed object or screwdriver until the valve switches and then turn the stem clockwise by 90° until the stop is reached. Valve remains switched.

2 Turn the stem anti-clockwise by 90° until the stop is reached and then remove the pointed object or screwdriver. Spring force pushes the stem of the MO back. The valve returns to its normal position (not the case with double solenoid valve code J).

Clip MO with lock onto the pilot

valve. The MO cap can then be operated (detenting) without tools. Valves can be ordered with a fitted cover cap in the valve terminal configurator using the selection menu "Manual override" (code Y).

MO with automatic return (non-detenting)



MO with lock - Actuation




screwdriver and reset by spring force (detenting position prevented by coded cover cap). Valves can be ordered with a fitted

Manual override is actuated by

pushing with a pointed object or

cover cap in the valve terminal configurator using the selection menu "Manual override" (code N).



- Cap locks into the end position.
- Pilot valve switches and actuates the main valve.


MO with lock - Actuation



Sliding the cap for the MO with lock in the direction of the arrow causes the following to happen:

- Cap locks into the end position.
- Spring force pushes the stem of the MO back.
- Pilot valve returns to its normal position as does the single solenoid main valve (not the case with double solenoid valve code J).

Inscription system




To label the valves, an inscription label holder VMPA1-ST-1-4 or VMPA1-ST-2-4 (for holding inscription labels IBS-6x10) can be fitted to each manifold block with a width of 42 mm. The inscription label holder ASLR-D-L1 can be pushed onto the manual

override.

As an alternative or in addition, large inscription labels can be applied to the pneumatic interface: Inscription labels 20 x 45 mm are suitable for this purpose, see → page 83

Key features - Electrical components

Electrical power as a result of current reduction



Individual valve

- Valves can also be used on individual sub-bases for actuators further away from the valve terminal.
- Detachable electronics module with integrated holding current reduction

pins up to 24 are left free. Pin 25 is

reserved for the neutral conductor.

positive or negative logic (PNP or

Each pin on the multi-pin plug can

actuate exactly one solenoid coil. If

the maximum configurable number

NPN). Mixed operation is not

permitted.

The valves are switched by means of

Each MPA solenoid coil is protected with a spark arresting protective circuit as well as against polarity reversal.

All valve types are additionally equipped with integrated current reduction. MPA valves are supplied with operating voltage in the range 18 ... 30 V (24 V +/-25%). This high tolerance is made possible through integrated control electronics and offers additional security, e.g. if the operating voltage drops.

• Electrical M8 connection, 4-pin with screw connection

- Note

More information about individual sub-bases can be found at:

Electrical multi-pin plug connection

The following multi-pin plug connection is offered for the valve terminal MPA:

• Sub-D multi-pin plug connection (25-pin)

Pins 1 ... 24 are used for addresses 1 ... 24 in order.

If fewer than 24 addresses are used for the valve terminal, the remaining

Guidelines on addressing for valves/solenoid coils

- The maximum possible number of addresses with a multi-pin plug connection is 24.
- Each manifold block/electronics module occupies a defined number of addresses/pins:
 - Manifold block MPA1 for 4 single solenoid valves: 4

- Manifold block MPA1 for 4 double solenoid valves: 8
- Manifold block MPA2 for 2 single solenoid valves: 2
- Manifold block MPA2 for 2 double solenoid valves: 4

that 24 valves can be addressed with one solenoid coil. With 12 or less valve positions, 2 sole-

of valve positions is 24, this means

with 12 of tess valve positions, 2 solenoid coils per valve can be addressed. With 12 or more valve positions, the number of available valve positions for valves with two solenoid coils decreases.



If a single solenoid valve is assembled on a double solenoid valve position, the second address is also occupied and cannot be used.

- The numbering of the addresses goes from left to right in ascending consecutive order. The following applies to the individual valve positions: address x for coil 14 and address x+1 for coil 12.
- If single solenoid valves are mounted on manifold blocks for double solenoid valves, the address of coil 12 and the assigned pin will remain unused.

Key features – Electrical components

AS-interface® fieldbus connection

The AS-interface facilitates the spatial distribution of individual components or small component groups. The AS-interface connection of valve terminal MPA can be used to control up to 8 solenoid coils. The electrical connection of the valve terminal contains the LEDs that indicate the signal status and the protective circuit for the valves.

- 📱 - Note

For further information see → Internet: as-interface

CPI fieldbus connection

All CP valve terminals and CP modules are connected using a ready-to-install CP cable, and are attached to the CP interface. Four modules, for example

one CPV valve terminal and one to three CP input modules, make up an installation string that ends at the CP interface. The installation system

supports a maximum of 4 installation strings that can be connected to a CP fieldbus node.

[≜] - Note

For further information see

➔ Internet: ctec

CPX fieldbus connection

All functions and features of the electrical peripherals CPX are supported in connection with the CPX interface. This means:

- The valves and electrical outputs are supplied via the operating voltage connection CPX
- The valves are supplied and disconnected separately via a separate valve connection on the CPX (code V)

- ↓ Note For further information see → Internet: cpx

Key features – Electrical components

Pin allocation – Sub-D socket cable

Pin allocation – Sub-D socket, cable	Pin	Address/coil	Wire colour ²⁾	Pin	Address/coil	Wire colour ²⁾
250 013 240 012 230 011 230 010 220 09 210 9	Pin 1 2 3 4 5 6 7	Address/coil 0 1 2 3 4 5 6	Wire colour ²) WH GN YE GY PK BU RD	Pin 17 18 19 20 21 22 23	Address/coil 16 17 18 19 20 21 22	Wire colour ²) WH PK PK BN WH BU BN BU WH RD BN RD WH BK
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	9 10 11 12 13 14 15	7 8 9 10 11 12 13 14	VT GY PK RD BU WH GN BN GN WH YE YE BN WH GY	24 25 - 🎍 - The drav	23 0 V ¹⁾ Note ving shows a view on i-pin cable VMPA-KM	BN BK the Sub-D socket on
0 1	16	14	GY BN			

0 V for positive switching control signals; connect 24 V for negative switching control signals; mixed operation is not permitted.
 To IEC 757.

Dimensions Download CAD data → www.festo.com Connecting cable 1 Cable conduit fitting with The wire colours refer to the following 1 clamping range 6 ... 12 mm pre-assembled multi-pin cables from Festo: • VMPA-KMS1-8-... Valve terminal for Ы up to 4 valve positions (8 coils) • VMPA-KMS1-24-... Valve terminal 11 12 with 8 ... 24 valve positions Ē 5 Ξ

Туре	L1	L2	B1	H1	H2	H3
VMPA-KMS-H	107.3	26	37.6	28	20	13.8

Туре	Sheath	Length	Core x mm ²	D	Part No.
		[m]		[mm]	
VMPA-KMS1-8-2.5	PVC	2.5	10 x 0.34	6.9	533195
VMPA-KMS2-8-2.5-PUR	PUR	2.5	10 x 0.25	8.3	533504
VMPA-KMS1-8-5	PVC	5	10 x 0.34	6.9	533196
VMPA-KMS2-8-5-PUR	PUR	5	10 x 0.25	8.3	533505
VMPA-KMS1-8-10	PVC	10	10 x 0.34	6.9	533197
VMPA-KMS2-8-10-PUR	PUR	10	10 x 0.25	8.3	533506
VMPA-KMS1-24-2.5	PVC	2.5	25 x 0.34	11.4	533192
VMPA-KMS2-24-2.5-PUR	PUR	2.5	25 x 0.25	11.2	533501
VMPA-KMS1-24-5	PVC	5	25 x 0.34	11.4	533193
VMPA-KMS2-24-5-PUR	PUR	5	25 x 0.25	11.2	533502
VMPA-KMS1-24-10	PVC	10	25 x 0.34	11.4	533194
VMPA-KMS2-24-10-PUR	PUR	10	25 x 0.25	11.2	533503
VMPA-KMS-H	Cover for self-asse	embly		·	533198

FESTO

Key features – Electrical components

Instructions for use

Equipment

Operate your equipment with unlubricated compressed air if possible. Festo valves and cylinders are designed so that, if used as designated, they will not require additional lubrication and will still achieve a long service life.

The quality of compressed air downstream from the compressor must correspond to that of unlubricated compressed air. If possible, do not operate all of your equipment with lubricated compressed air. The lubricators should, where possible, always be installed directly upstream of the actuator used. Unsuitable additional oil and an excessive oil content in the compressed air reduce the service life of the valve terminal.

Use Festo special oil OFSW-32 or the alternatives listed in the Festo catalogue (as specified in DIN 51524 HLP32; basic oil viscosity 32 CST at 40 °C).

Bio-oils

When using bio-oils (oils that are based upon synthetic or native ester, e.g. rapeseed oil methyl ester), the maximum residual oil content of 0.1 mg/m³ must not be exceeded (see ISO 8573-1 Class 2).

Mineral oils

When using mineral oils (e.g. HLP oils to DIN 51524, parts 1 to 3) or similar oils based on poly-alpha-olefins (PAO), the maximum residual oil content of 5 mg/m³ must not be exceeded (see ISO 8573-1 Class 4). A higher residual oil content irrespective of the compressor oil cannot be permitted, as the basic lubricant would be flushed out over time.


Technical data

FESTO

- N Flow rate MPA1: Up to 360 l/min MPA2: Up to 700 l/min
- **[]** Valve width MPA1: 10 mm

MPA2: 20 mm

- **L** - Voltage 24 V DC



General technical data							
Valve terminal design		Modular, valve sizes	can be mixed				
Electrical actuation		Fieldbus	Multi-pin plug	AS-i interface	CPI interface		
Actuation type		Electric	·				
Nominal voltage	[V DC]	24					
Operating voltage range	[V DC]	18 30					
Residual ripple	[Vss]	4					
Max. no of valve positions		64 (FB), 24 (MP)					
Valve size	[mm]	10, 20					
Pilot air supply		Internal or external					
Lubrication		Life-time lubrication,	PWIS-free (free of paint-wetting i	mpairment substances)			
Type of mounting		Wall mounting					
		On H-rail to EN 60715					
Mounting position		Any (wall mounting)					
		Horizontal only (H-rai	l)				
Manual override		Non-detenting, deten	ting				
Protection class to EN 60529		IP65 (for all types of s	ignal transmission in assembled	l state)			
Pneumatic connections							
Pneumatic connection		Via manifold block or	individual connection				
Supply port	1	G1/4 (M7 with individ	lual sub-base)				
Exhaust port	3/5	QS-10, QS-3/8" (M7	vith individual sub-base)				
Working ports	2/4	Dependent on the cor	nection type selected				
		MPA1: M7, QS4, QS6, 3/16", 1/4"					
		MPA2: G1/8, QS6, QS	8,1/4",5/16"				
Pilot air port	12/14	M7 (M5 with individu	al sub-base)				
Pilot exhaust air port	82/84	M7 (M5 with individu	al sub-base)				
Pressure compensation port		With ducted exhaust air: via port 82/84 (M5 for individual sub-base and for end plate VMPA-EPR-G)					
		With flat plate silencer: exhaust to atmosphere					



Note possible restrictions for the IP protection class → ATEX conformity declaration

Technical data

Operating and environmental conditions

Operating medium		Compressed air according to ISO 8573-1:2010 [7:4:4]
Note on operating/pilot medium		Lubricated operation possible (in which case lubricated operation will always be required)
Operating pressure	[bar]	-0.9 10
Pilot pressure	[bar]	38
Ambient temperature	[°C]	-5 +50
Temperature of medium	[°C]	-5 +50
Storage temperature ¹⁾	[°C]	-20 +40
Relative air humidity		Max. 90 % at 40 °C

1) Long-term storage

Cortifications1)


Certifications ¹⁾					
Туре	MPA-MPM-VI	MPA-FB-VI	MPA-ASI-VI	MPA-CPI-VI	
	(multi-pin plug interface)	(fieldbus interface)	(AS-i interface)	(CPI interface)	
Part number	539105	530411	546279	546280	
ATEX category for gas	II 3 G		II 3 G		
Explosion ignition protection type for gas	Ex nA IIC T4 X Gc	Ex nA IIC T4 Gc	Ex nA IIC T4 X Gc		
ATEX temperature rating [°C]	–5 ≤ Ta ≤ +50		-5 ≤ Ta ≤ +50		
Explosion protection certification outside	-	EPL Gc (BR)	-	-	
the EU					
Certificate issuing authority	-	DNV 15.0189X	-	-	
CE marking	To EU EMC Directive ²⁾				
(see declaration of conformity)	To EU Explosion Protection				
	Directive (ATEX)	Directive (ATEX)	Directive (ATEX)	Directive (ATEX)	
Certification	cULus recognized (OL)	cULus recognized (OL)	cULus recognized (OL)	cULus recognized (OL)	
Corrosion resistance class CRC ³⁾	1	1	0	0	

1) Interface versions not listed do not have any of the listed certifications


For information about the applicability of the component see the manufacturer's EC declaration of conformity at: www.festo.com/sp → User documentation. If the component is subject to restrictions on usage in residential, office or commercial environments or small businesses, further measures to reduce the emitted interference may be necessary.
 Corrosion resistance class 1 according to Festo standard 940 070 Components subject to low corrosion stress. Transport and storage protection. Parts that do not have primarily decorative surface requirements, e.g. in internal areas that are not visible or behind covers.

Technical data


Pilot pressure p2 as a function of working pressure p1 with external pilot air supply




Pilot pressure p2 as a function of working pressure p1 for valves with mechanical spring return



For valves in width 10 mm with code: MU, NU, KU, HU



For valves in width 20 mm with code: MS, NS, KS, HS, DS




Technical data


(P regulator plate) for port 1 (B regulator plates) for port 2 7 7 6 6 5 5 p2 [bar] p2 [bar] 4 4 3 3-2 2-1 1 0 0-200 400 600 800 1000 0 0 200 400 600 800 1000 qn [l/min] qn [l/min] Supply pressure 10 bar, Supply pressure 10 bar, set regulated pressure 6 bar set regulated pressure 6 bar

Flow rate qn as a function of output pressure p2 with pressure regulator plates (width 20 mm)


Flow rate qn as a function of output pressure p2 with pressure regulator plates (width 20 mm) (A regulator plates) for ports 4 (B regulator p



(B regulator plates, rev.) for ports 3, reversible




Supply pressure 10 bar, set regulated pressure 6 bar



Flow rate qn as a function of output pressure p2 with pressure regulator plates (width 20 mm)

(A regulator plates, rev.) for ports 5, reversible



Supply pressure 10 bar, set regulated pressure 6 bar



Technical data

FESTO

Technical data – Valves in width 10 mm

Code			М	J	Ν	К	Н	В	G	E	Х	W	D	I
Switching times On		[ms]	10	10	10	10	10	10	10	10	10	10	10	10
	Off	[ms]	20	-	20	20	20	35	35	35	20	20	20	20
	Change-	[ms]	-	15	-	-	-	15	15	15	-	-	-	-
	over													
Operating pressure		[bar]	-0.9 +	10	3 10			-0.9	+10				3 10	
Standard nominal fl	ow rate	[l/min]	360	360	300	230	300	300	320	240	255	255	230	260
Design			Piston s	oool valve										
Max. tightening torq	ue of	[Nm]	0.25											
valve mounting														
Materials			Die-cast	aluminium										
Product weight		[g]	49	56	56	56	56	56	56	56	49	49	56	56

Technical data – Va	alves in wid	th 10 mm									
Code			MS	NS	KS	HS	DS	MU	NU	KU	HU
Switching times	On	[ms]	10	14	14	14	14	10	8	8	8
	Off	[ms]	27	16	16	16	16	12	8	10	10
	Change-	[ms]	-	-	-	-	-	-	-	-	-
	over										
Operating pressure		[bar]	-0.9 +8					-0.9 +10			
Standard nominal f	low rate	[l/min]	360	300	230	300	230	190	190	160	190
Design			Piston spool	valve				Poppet valve	with spring r	eturn	
Max. tightening tore	que of	[Nm]	0.25								
valve mounting											
Materials			Die-cast alu	ninium				Reinforced P	PA		
Product weight		[g]	56	56	56	56	56	35	42	42	42

Technical data – Va	lves in wid	th 20 mm																	
Code			М	J	Ν	Κ	Н	В	G	E	Х	W	D	1	MS	NS	KS	HS	DS
Switching times	On	[ms]	15	9	8	8	8	11	10	11	13	13	7	7	8	12	12	12	12
	Off	[ms]	28	-	28	28	28	46	40	47	22	22	25	25	36	25	25	25	25
	Change-	[ms]	-	22	-	-	-	23	21	23	-	-	-	-	-	-	-	-	-
	over																		
Operating pressure		[bar]	-0.9 .	+10	3 1	0		-0.9	. +10				3 1	0	-0.9 .	. +8			
Standard nominal fl	ow rate	[l/min]	700	670	550	500	550	510	610	590	470	470	650	680	670	550	500	550	650
Design			Pistor	n spool v	valve														
Max. tightening toro	ue of	[Nm]	0.65																
valve mounting																			
Materials			Die-ca	ist alum	ninium														
Product weight		[g]	100																

Technical data

Electrical data – MPA with electronics module VI	ЛРАFB (СР	X terminal, CPI interface)	
		MPA1	MPA2
Intrinsic current consumption per electronics mod	ule		
At 24 V U _{EL/SEN} ¹⁾	[mA]	Typically 8	
(internal electronics, all outputs 0 signal)			
At 24 V Uval ²⁾			
(internal electronics, without valves)			
VMPAEMG, separate circuits	[mA]	Typically 23 mA	
VMPAEMS, with separate circuits	[mA]	Typically 3 mA	
Maximum current consumption per solenoid coil a	at nominal volt	age	
Nominal pick-up current	[mA]	58	99
Nominal current following current reduction	[mA]	9	18
Time until current reduction	[ms]	24	24
Diagnostic message			
Undervoltage U _{OFF} ³⁾	[V]	17.5 16	

Electrical data – MPA with electronics module VMPAMPM (AS-i interface, multi-pin plug)							
		MPA1	MPA2				
Current consumption at Sub-D multi-pin plug connection per solenoid coil at nominal voltage							
Nominal pick-up current	[mA]	80	100				
Nominal current with current reduction	[mA]	25	20				
Time until current reduction	[ms]	25	50				

Calculation example for current consumption (CPX terminal, CPI interface)						
Current consumption with two solenoid coils MPA2 switched in parallel and one electronics module VMPAEMS without separate circuits	[mA]	I _{EI/SEN} = 8				
Nominal pick-up current (duration 24 ms)	[mA]	$I_{VAL} = 3$ (intrinsic current consumption of electronics module) + 2 x 99 (MPA2) = 202				
Nominal current with current reduction (after 24 ms)	[mA]	l _{VAL =} 3 (intrinsic current consumption of electronics module) + 2 x 18 (MPA2) = 39				

Power supply for electronics and sensors
 Load voltage supply for valves
 Load voltage outside of function range

Technical data

Data on vibration and shock^{1) 2) 4)} to DIN/EC68

Vibration	Tested according to DIN/IEC68 / EN60068 parts 2 6
	With horizontal H-rail mounting: severity level 1
	With wall mounting: ^{2) 3)}
Shock	Tested according to DIN/IEC68 / EN60068 parts 2 27
	With horizontal H-rail mounting: severity level 1
	With wall mounting: severity level 1 2 ²⁾
Continuous shock	Tested according to DIN/IEC68 / EN 60068 parts 2 29
	With wall and H-rail mounting: severity level 1

1) See the CPX System manual for information on vibration and shock for the CPX terminal.

2) Valve terminal MPA-S with CPX terminal:

up to a length of 280 mm between the pneumatic interface and right-hand end plate, without additional fastening: severity level 2 above a length of 280 mm between the pneumatic interface and right-hand end plate, with additional fastening at the pneumatic supply plates: severity level 2
3) Valve terminal MPA-S with CPI, with AS-i or with multi-pin plug connection:

up to a valve terminal length of 280 mm, without additional fastening: severity level 2

above a valve terminal length of 280 mm, with at least one additional fastening in the centre of the valve terminal at the pneumatic supply plate: severity level 2

4) See table below for explanations of the severity levels.

Test conditions					
Severity level	Vibration	Shock	Continuous shock		
1	0.15 mm travel at 10 58 Hz,	±15 g at 11 ms duration,	±15 g at 6 ms duration,		
	2 g acceleration at 58 150 Hz	5 shocks per direction	1,000 shocks per direction		
2	0.35 mm travel at 10 60 Hz,	±30 g at 11 ms duration,	-		
	5 g acceleration at 60 150 Hz	5 shocks per direction			
Continuous shock resistance To DIN/IEC 68/EN 60068, parts 2-29: +/-15 g at 6 ms, 1,000 cycles					


Technical data

Materials	
Manifold block	Die-cast aluminium
Seals	NBR, elastomer
Supply plate	Die-cast aluminium
Right-hand end plate	Die-cast aluminium
Left-hand pneumatic interface	Die-cast aluminium, PA
Exhaust plate	РА
Flat plate silencer	PE
Electrical supply plate	Housing: Die-cast aluminium
	End cap: Reinforced PA
Electronics module	РА
Electrical interlinking module	Bronze/PBT
Regulator plate	Control section, housing: PA; Seals: NBR
Note on materials	RoHS-compliant

Product weight		
Approx. weight [g]	MPA1	MPA2
Manifold block basic weight ¹⁾	400 (4 valve positions)	400 (2 valve positions)
Sub-base ¹⁾	180	
Individual sub-base	92	233
Per vacant position L	20	45
Right-hand end plate	55	
Left-hand pneumatic interface ¹⁾		
• With flat plate silencer	315	
With ducted exhaust air	324	
Supply plate ¹⁾		
• With flat plate silencer	111	
With ducted exhaust air	120	
Electrical supply plate	200	
Regulator plate (MPA1)	73.8	
Regulator plate (MPA2)	180	
QSM-M5-3-I	3	
QSM-M5-5/32-I-U-M	3	
QSM-M5-4-I	4	
QSM-M5-3/16-I-U-M	4	
QSM-M5-6-I	5	
QSM-M5-1/4-I-U-M	5	
QSM-M7-4-I	4	
QSM-M7-3/16-I-U-M	4	
QSM-M7-6-I	5	
QSM-M7-1/4-I-U-M	5	
QS-G1⁄/8-6-l	11	
QS-1/8-1/4-I-U-M	11	
QS-G1⁄/8-8-l	13	
QS-1/8-5/16-I-U-M	13	
QS-G1⁄4-8-I	22	
QS-1/4-5/16-I-U-M	22	
QS-G ¹ /4-10-I	22	
QS-1/4-3/8-I-U-M	22	


1) With sheet metal seal, inscription label holder, screws

Technical data




Technical data

FESTO




Technical data





Technical data


FESTO



1) m = number of CPX modules


Technical data

Dimensions



Туре	H1	L1	L2	L3
VMPA1	105	151.1	122.3	26.9


Vertical stacking components, regulator plate VMPA2



Туре	H1	L1	L2	L3
VMPA2	152	179.6	131.6	26.9

Download CAD data → www.festo.com

Technical data – Proportional pressure regulator VPPM





FESTO

General technical data					
			VPPM-6TA	VPPM-8TA	
Valve function			3-way proportional pressure reg	ulator	
Design			Piloted diaphragm regulator		
Type of mounting			Via through-hole or accessories		
Sealing principle			Soft		
Actuation type			Electric		
Type of control			Piloted		
Mounting position		Any			
Reset method			Mechanical spring		
Display type			LED	Back illuminated LCD	
Pneumatic connection	1, 2, 3		Sub-base		
Nominal size	Pressurisation	[mm]	6	8	
	Exhaust	[mm]	4.5	7	
Standard nominal flow rate	Standard nominal flow rate 2 bar type [l/mir		380	450	
	6 bar type	[l/min]	900	1050	
	10 bar type	[l/min]	1400	1650	
Product weight		[g]	400	500	
Materials	Housing		Anodised wrought aluminium all	loy	


Electrical data						
Electrical connection		Via sub-base				
Operating voltage range	[V DC]	21.6 26.4				
Residual ripple	[%]	10				
Max. electrical power consumption	[W]	7				
Duty cycle	[%]	100				
Protection against short circuit		For all electrical connections				
Reverse polarity protection		For all electrical connections				
Protection class to EN 60529		IP65				

- 闄 - Note
Output pressure is maintained un-
regulated if the power supply cable
is interrupted.


- 🖡 - Note


Note possible restrictions for the IP protection class → ATEX conformity declaration

Technical data - Proportional pressure regulator VPPM





Technical data – Proportional pressure regulator VPPM






Flow rate qn from 2→3 as a function of output pressure p2 VPPM-8TA-...-0L2H-... (2 bar)







Technical data – Proportional pressure regulator VPPM

FESTO

Operating and environmental conditions

			VPPM-6TA	VPPM-8TA		
Operating medium			Compressed air according to ISC	Compressed air according to ISO 8573-1:2010 [7:4:4]		
			Inert gases			
Note on operating/pilot medium			Lubricated operation not possib	le		
Pressure regulation range	VPPM0L2H	[bar]	0.02 2			
	VPPM0L6H	[bar]	0.06 6			
	VPPM0L10H	[bar]	0.1 10			
Supply pressure 1 ¹⁾	VPPM0L2H	[bar]	0 4			
	VPPM0L6H	[bar]	0 8			
	VPPM0L10H	[bar]	0 11			
Max. pressure hysteresis	VPPM0L2H	[bar]	0.01			
	VPPM0L6H	[bar]	0.03			
	VPPM0L10H	[bar]	0.05			
FS (full scale) linearity error	Standard	[%]	2			
	Type S1	[%]	1			
FS (full scale) repetition accuracy		[%]	0.5			
Temperature coefficient		[%/K]	0.04			
Ambient temperature		[°C]	0 60	0 50		
Temperature of medium [°C]		10 50				
Corrosion resistance class CRC ²⁾			2			
CE marking (see declaration of conformity)			To EU EMC Directive ³⁾			
Certification		cULus recognized (OL)	-			
			C-Tick	· · · ·		


1) Supply pressure 1 should always be 1 bar greater than the maximum regulated output pressure. 2) Corrosion resistance class 2 according to Festo standard 940 070

Components subject to moderate corrosion stress. Externally visible parts with primarily decorative surface requirements which are in direct contact with a normal industrial environment or media such as coolants or lubricating agents.

3)


To information about the applicability of the component see the manufacturer's EC declaration of conformity at: www.festo.com/sp 🗲 User documentation. If the component is subject to restrictions on usage in residential, office or commercial environments or small businesses, further measures to reduce the emitted interference may be necessary.

LEDs on the proportional pressure regulator VPPM-6TA



1	Green power LED	
2	Red error LED	

Technical data – Proportional pressure regulator VPPM



Туре	B1	D5 Ø	H2	H3	H4	H5	H8	H9	H10	H11	H13
VPPM-8TA	77.4	8	110.4	80	52.8	41.3	28.3	26.3	23	12.2	95.5
Туре	L1		L2		L3	L4		L5	L6		L7
VPPM-8TA	41.5		31.5		29.3	28.4		12.3	25		9.9

Technical data – Proportional pressure regulator VPPM

Ordering data					
Code	Overall accuracy [%]	Supply pressure 1 [bar]	Pressure regulation range [bar]	Part No.	Туре
QA	2	0 4	0.02 2	542220	VPPM-6TA-L-1-F-0L2H
QD	1	0 4	0.02 2	542217	VPPM-6TA-L-1-F-0L2H-S1
QB	2	0 8	0.06 6	542221	VPPM-6TA-L-1-F-0L6H
QE	1	0 8	0.06 6	542218	VPPM-6TA-L-1-F-0L6H-S1
QC	2	0 11	0.1 10	542222	VPPM-6TA-L-1-F-0L10H
QF	1	0 11	0.1 10	542219	VPPM-6TA-L-1-F-0L10H-S1
QL	1	0 4	0.02 2	572407	VPPM-8TA-L-1-F-0L2H-S1C1
QG	2	0 4	0.02 2	572410	VPPM-8TA-L-1-F-0L2H-C1
QM	1	0 8	0.06 6	572408	VPPM-8TA-L-1-F-0L6H-S1C1
QH	2	0 8	0.06 6	572411	VPPM-8TA-L-1-F-0L6H-C1
QN	1	0 11	0.1 10	572409	VPPM-8TA-L-1-F-0L10H-S1C1
QK	2	0 11	0.1 10	572412	VPPM-8TA-L-1-F-0L10H-C1

Ordering data – Acces	ssories		
Designation		Part No.	Туре
	Mounting	558844	VMPA-BG
	Sub-base without electrical interlinking module or electrical module	542223	VMPA-FB-AP-P1
	Blanking plate	559638	VMPA-P-RP
	Electrical interlinking module for sub-base of the proportional pressure regulator	537998	VMPA1-FB-EV-AB
	Electrical module	542224	VMPA-FB-EMG-P1

Accessories

Ordering data					
	Code	Valve function	Width	Part No.	Туре
			[mm]		
ividual solenoid	valves				
R.a.	5/2-way	valve			
	М	Single solenoid	10	533342	VMPA1-M1H-M-PI
			20	537952	VMPA2-M1H-M-PI
	MS	Single solenoid, mechanical spring return	10	571334	VMPA1-M1H-MS-PI
\checkmark			20	571333	VMPA2-M1H-MS-PI
	MU	Polymer poppet valve,	10	553113	VMPA1-M1H-MU-PI
10 00		single solenoid, mechanical spring return			
	J	Double solenoid	10	533343	VMPA1-M1H-J-PI
			20	537953	VMPA2-M1H-J-PI
	2x 3/2-v	vay valve			
	Ν	Normally open	10	533348	VMPA1-M1H-N-PI
			20	537958	VMPA2-M1H-N-PI
	NS	Normally open, mechanical spring return	10	556839	VMPA1-M1H-NS-PI
			20	568655	VMPA2-M1H-NS-PI
	NU	Polymer poppet valve,	10	553111	VMPA1-M1H-NU-PI
		normally open, mechanical spring return			
	К	Normally closed	10	533347	VMPA1-M1H-K-PI
			20	537957	VMPA2-M1H-K-PI
	KS	Normally closed,	10	556838	VMPA1-M1H-KS-PI
		mechanical spring return	20	568656	VMPA2-M1H-KS-PI
	KU	Polymer poppet valve, normally closed,	10	553110	VMPA1-M1H-KU-PI
		mechanical spring return			
	Н	1x normally open,	10	533349	VMPA1-M1H-H-PI
		1x normally closed	20	537959	VMPA2-M1H-H-PI
	HS	1x normally open,	10	556840	VMPA1-M1H-HS-PI
		1x normally closed,			
		mechanical spring return	20	568658	VMPA2-M1H-HS-PI
	HU	Polymer poppet valve,	10	553112	VMPA1-M1H-HU-PI
	_	1x normally open,	-		
		1x normally closed,			
		mechanical spring return			
	5/3-way				
	B	Mid-position pressurised	10	533344	VMPA1-M1H-B-PI
	-	····	20	537954	VMPA2-M1H-B-PI
	G	Mid-position closed	10	533345	VMPA1-M1H-G-PI
	Ĩ		20	537955	VMPA2-M1H-G-PI
	E	Mid-position exhausted	10	533346	VMPA1-M1H-E-PI
	-		20	537956	VMPA2-M1H-E-PI
	3/2-way	valve	20		
	W	Normally open,	10	540050	VMPA1-M1H-W-PI
		external compressed air supply	20	540050	VMPA2-M1H-W-PI
	х	Normally closed,	10	534415	VMPA1-M1H-X-PI
	^	external compressed air supply	20	537961	VMPA2-M1H-X-PI
	2x 2/2-1	vay valve	20	337301	
	D	Normally closed	10	533350	VMPA1-M1H-D-PI
	U	Normally closed	20	537960	VMPA1-M1H-D-PI
	DS	Normally closed,	10	556841	VMPA2-M1H-D-PI VMPA1-M1H-DS-PI
	20				
	1	mechanical spring return	20	568657	VMPA2-M1H-DS-PI
		1x normally closed	10	543605	VMPA1-M1H-I-PI
		1x normally closed, reversible only	20	543703	VMPA2-M1H-I-PI

FESTO

Accessories

Ordering data – Vert	ical stacking	g modules, width 10 n	nm			
	Code	Description			Part No.	Туре
Pressure regulator pla	ate, M5 inter	face for pressure gaug	e connection, fixed			
പീ	PF	For connection 1	Pressure regulation rang	e 0.5 5 bar	564911	VMPA1-B8-R1-M5-06
	PA]	Pressure regulation rang	e 0.5 8.5 bar	564908	VMPA1-B8-R1-M5-10
	PH	For connection 2	Pressure regulation rang	e 2 5 bar	564912	VMPA1-B8-R2-M5-06
N N N	PC		Pressure regulation rang	e 2 8.5 bar	564909	VMPA1-B8-R2-M5-10
لقلر ٢	PG	For connection 4	Pressure regulation rang	e 2 5 bar	564913	VMPA1-B8-R3-M5-06
	PB		Pressure regulation rang	e 2 8.5 bar	564910	VMPA1-B8-R3-M5-10
	1	1				
Pressure regulator pla	ate, M5 inter	face for pressure gaug	e connection, rotatable			
~ 1	PF	For connection 1	Pressure regulation range 0.5 5 bar		549052	VMPA1-B8-R1C2-C-06
	PA		Pressure regulation rang	e 0.5 8.5 bar	543339	VMPA1-B8-R1C2-C-10
	PH	For connection 2	Pressure regulation rang	e 2 5 bar	549053	VMPA1-B8-R2C2-C-06
	PC		Pressure regulation rang	je 2 8.5 bar	543340	VMPA1-B8-R2C2-C-10
	PG	For connection 4	Pressure regulation rang		549054	VMPA1-B8-R3C2-C-06
	PB		Pressure regulation rang		543341	VMPA1-B8-R3C2-C-10
Pressure gauge for pr	essure regul	ator plate				
	VE	M5 interface,	Operating pressure	Display unit 0 10 bar	132340	MA-15-10-M5
		rotatable	0 10 bar			
	VD	Totatable	0 10 bui	Display unit 0 145 psi	132341	MA-15-145-M5-PSI
Buch in fitting colf of	aling					
Push-in fitting, self-se	anng	For MPA1, M5 interfa	uco fivod		153291	QSK-M5-4
a II	-	FOR MPA1, M5 Interna	ice, fixed		153291	Q3K-M3-4
Vertical pressure shu	t-off plate					
Raca.	PS	For manually disconr	necting individual valves fro	om the compressed air supply	567805	VMPA1-HS
		of the valve terminal	(duct 1 and 12/14 pilot air	supply), operating pressure		
		3 8 bar				
4						
Fixed restrictor						
	-	Hollow bolt for restri	icting the exhaust air in	4.5 l/min	572544	VMPA1-FT-NWQ3-10
		duct 3 and 5		10.5 l/min	572545	VMPA1-FT-NWQ5-10
		(for width 10 mm onl	w)	20.0 l/min	572545	VMPA1-FT-NW05-10
\cup		•	y)			
		(10 pieces)		38.5 l/min	572547	VMPA1-FT-NW1.0-10
				55.0 l/min	572548	VMPA1-FT-NW1.2-10
				85.0 l/min	572549	VMPA1-FT-NW1.5-10
				110.0 l/min	572550	VMPA1-FT-NW1.7-10
Restrictor set		I = .				
	-	Fixed restrictors, two			572543	VMPA1-FT-NW0.3-1.7
9 🛞 (two retainers and ass	sembly tool			
Retainer for fixed rest	rictor	-				
	-		opening in the sub-base		572542	VMPA1-FTI-10
		(10 pieces)				
S A						
\sim						

Accessories

Ordering data – Vertical stacking modules, width 10 mm

	Code	Description		Part No.	Туре
Non-return valve					
	-	Installation in duct 3 or 5 of the appropriate s (scope of delivery: 10 valve inserts, 20 balls, tool; sufficient for 10 non-return valves)		8039819	VMPA1-RV
Sub-bases for non-	return valve i	nstallation For multi-pin plug/fieldbus, four valve	No duct separation	578860	VMPA1-FB-APF-4-1
		positions, no electrical interlinking module	Duct 1 blocked	578861	VMPA1-FB-APF-4-1-T1
		, ,	Duct 1 blocked and duct 3/5 blocked	578862	VMPA1-FB-APF-4-1-S1
				1	
Sub-bases with ins	talled non-re	turn valve in duct 3 and 5			
	-	For multi-pin plug/fieldbus, four valve	No duct separation	8034547	VMPA1-FB-AP-4-1-RV
		positions, no electrical interlinking module	Duct 1 blocked	8034549	VMPA1-FB-AP-4-1-T1-RV
			Duct 1 blocked and duct 3/5 blocked	8034551	VMPA1-FB-AP-4-1-S1-RV

FESTO

Accessories

Ordering data – Vertical stacking modules, width 20 mm

Ordering data – Vert	Code	g modules, width 20 m	m		Part No.	Туре
Droccuro regulator			or processo areas	reconnection processes seculates		ijpc
riessure regulator pl	PF	For connection 1		ge connection, pressure regulator not ation range 0,5 5 bar	549055	VMPA2-B8-R1C2-C-06
1	PF		_	ation range 0,5 8,5 bar	543342	VMPA2-B8-R1C2-C-06
	PH	For connection 2	-	ation range 2 5 bar	549056	VMPA2-B8-R1C2-C-10
	PC		_	ation range 2 8,5 bar	543343	VMPA2-B8-R2C2-C-00
	PG	For connection 4	_	ation range 2 5 bar	549057	VMPA2-B8-R3C2-C-06
	PB	=	_	ation range 2 8,5 bar	543344	VMPA2-B8-R3C2-C-10
	1			-		
Pressure regulator pl	ate with car	tridge 10 mm interface f	for pressure gaug	ge connection, pressure regulator not	reversible	
м́ -	PN	For connection 2	Pressure regul	ation range 0,5 5 bar	549113	VMPA2-B8-R6C2-C-06
rai S	PL	1	Pressure regul	ation range 0,5 8,5 bar	543347	VMPA2-B8-R6C2-C-10
	PM	For connection 4	Pressure regul	ation range 0,5 5 bar	549114	VMPA2-B8-R7C2-C-06
	РК	1	Pressure regul	ation range 0,5 8,5 bar	543348	VMPA2-B8-R7C2-C-10
	1		1		I	
Pressure gauge for pr	essure regu	llator plate				
	Т	Cartridge	Operating pres	ssure/display unit 0 10 bar	543488	PAGN-26-10-P10
		connection 10 mm		ssure/display unit 0 16 bar	543487	PAGN-26-16-P10
	-		1 01	ssure/display unit 0 1.0 MPa	563736	PAGN-26-1M-P10
			Operating pres	ssure/display unit 0 1.6 MPa	563735	PAGN-26-1.6M-P10
Threaded adapter for	pressure re			1.64.10		050 40 54 0
	-	10 mm cartridge conr	nection on thread	d G1/8	565811	QSP-10-G1/8
Vertical	nhurl-1					
Vertical pressure sup	ply plate PV	With connecting threa	ad	G1⁄8	8029486	VMPA2-VSP-0
					0023400	
สนิ		With fitting for tubing	0.D.	6 mm	8035441	VMPA2-VSP-QS6
				8 mm	8029488	VMPA2-VSP-QS8
				10 mm	8029489	VMPA2-VSP-QS10
				1/4"	8035442	VMPA2-VSP-QS1/4
The real real real real real real real rea				5/16"	8029491	VMPA2-VSP-QS5/16
New web.com						
Non-return valve	-	Installation in duct 3	or 5 of the approx	priate cub bases	9020021	VMPA2-RV
<u>I</u>	-	(scope of delivery: 10			8039821	VIVIĽAZ-KV
UHH		(Scope of delivery: 10	non return valve	, I assembly LUUI)		
~	1					
Sub-bases for non-re	turn valve i	nstallation				
	-	For multi-pin plug/	No duct separa	ation	578863	VMPA2-FB-APF-2-1
		fieldbus, two valve	Duridal	4	F 700 / /	
		positions, no elec-	Duct 1 blocked]	578864	VMPA2-FB-APF-2-1-T0
A Mar		trical interlinking	Duct 1 blocked	d and duct 3/5 blocked	578865	VMPA2-FB-APF-2-1-S0
		module				
			_			
Sub-bases with insta	lled non-ret	turn valve in duct 3 and	1		000/-//	
	-	For multi-pin plug/	No duct separa	ation	8034548	VMPA2-FB-AP-2-1-RV
		fieldbus, two valve	Duct 1 blocked	1	8034550	VMPA2-FB-AP-2-1-TO-RV
		positions, no elec-				
- F		trical interlinking	Duct 1 blocked	d and duct 3/5 blocked	8034552	VMPA2-FB-AP-2-1-S0-RV
		module				

Accessories

Ordering data – Proportional pressure regulator

Code	Full-scale linearity error	Supply pressure 1	Pressure regulation	Part No.	Туре
			range		
QA	2%	0 4 bar	0.02 2 bar	542220	VPPM-6TA-L-1-F-0L2H
QD	1%	0 4 bar	0.02 2 bar	542217	VPPM-6TA-L-1-F-0L2H-S1
QB	2%	0 8 bar	0.06 6 bar	542221	VPPM-6TA-L-1-F-0L6H
QE	1%	0 8 bar	0.06 6 bar	542218	VPPM-6TA-L-1-F-0L6H-S1
QC	2%	0 11 bar	0.1 10 bar	542222	VPPM-6TA-L-1-F-0L10H
QF	1%	0 11 bar	0.1 10 bar	542219	VPPM-6TA-L-1-F-0L10H-S1
QL	1%	0 4 bar	0.02 2 bar	572407	VPPM-8TA-L-1-F-0L2H-S1C1
QG	2%	0 4 bar	0.02 2 bar	572410	VPPM-8TA-L-1-F-0L2H-C1
QM	1%	0 8 bar	0.06 6 bar	572408	VPPM-8TA-L-1-F-0L6H-S1C1
QH	2%	0 8 bar	0.06 6 bar	572411	VPPM-8TA-L-1-F-0L6H-C1
QN	1%	0 11 bar	0.1 10 bar	572409	VPPM-8TA-L-1-F-0L10H-S1C1
QK	2%	0 11 bar	0.1 10 bar	572412	VPPM-8TA-L-1-F-0L10H-C1

Ordering data					
escription			Width [mm]	Part No.	Туре
			fuuul		
ub-base – Withou	t electrical interlinking module			I	
	For multi-pin plug/fieldbus	Four valve positions	10	533352	VMPA1-FB-AP-4-1
		Two valve positions	20	538000	VMPA2-FB-AP-2-1
	For multi-pin plug/fieldbus, duct 1 closed	Four valve positions	10	538657	VMPA1-FB-AP-4-1-T1
		Two valve positions	20	538677	VMPA2-FB-AP-2-1-T0
	For multi-pin plug/fieldbus, duct 1 closed	Four valve positions	10	555901	VMPA1-FB-AP-4-1-S1
	and duct 3/5 closed	Two valve positions	20	555902	VMPA2-FB-AP-2-1-S0
ub-base – Inci. ele	ectrical interlinking module and electronics mod		40	5//000	
สาโ	For fieldbus	Four valve positions	10	546802	VMPA1-AP-4-1-EMS-8
		Two valve positions	20	546803	VMPA2-AP-2-1-EMS-4
	For multi-pin plug	Four solenoid coils	10	546806	VMPA1-AP-4-1-EMM-4
		Two solenoid coils	20	546807	VMPA2-AP-2-1-EMM-2
20 Mar		Eight solenoid coils	10	546804	VMPA1-AP-4-1-EMM-8
		Four solenoid coils	20	546805	VMPA2-AP-2-1-EMM-4
ub-base – For Indi -	vidual connection Without ATEX specification	Internal pilot air	10	533394	VMPA1-IC-AP-1
Ϋ́.	without ATEX specification	internat phot an	20		
		Eutomal utilation	-	537981	VMPA2-IC-AP-1 VMPA1-IC-AP-S-1
U. Con		External pilot air	10	533395	
000000			20	537982	VMPA2-IC-AP-S-1
	With ATEX specification:	Internal pilot air	10	8005149	VMPA1-IC-AP-1-EX1E
	II 3G Ex nA IIC T4 XGc		20	8005151	VMPA2-IC-AP-1-EX1E
		External pilot air	10	8005150	VMPA1-IC-AP-S-1-EX1E
			20	8005152	VMPA2-IC-AP-S-1-EX1E
Ib-base - For prov	portional pressure regulator				
	Without electrical interlinking module or ele	ctrical module		542223	VMPA-FB-AP-P1

FESTO

Accessories

Ordering data					
Description				Part No.	Туре
End plate and fieldb	us pneumatic interface				
	Right-hand end plate			533373	VMPA-EPR
	Right-hand end plate with port 82/84 f		cting thread M5)	8029133	VMPA-EPR-G
	Pneumatic interface, ducted exhaust a	•		533370	VMPA-FB-EPL-G
	Pneumatic interface, ducted exhaust a	ir, internal pilot air, for CPX r	netal interlinking	552286	VMPA-FB-EPLM-G
	module				
	Pneumatic interface, ducted exhaust a Pneumatic interface, ducted exhaust a		motal interlinking	533369 552285	VMPA-FB-EPL-E VMPA-FB-EPLM-E
	module		inetat intertinking	552265	VMFA-FD-EFEW-E
\checkmark	Pneumatic interface, flat plate silencer	internal nilot air		533372	VMPA-FB-EPL-GU
	Pneumatic interface, flat plate silencer		etal interlinking	552288	VMPA-FB-EPLM-GU
	module	,	3		
	Pneumatic interface, flat plate silencer	, external pilot air		533371	VMPA-FB-EPL-EU
	Pneumatic interface, flat plate silencer	, external pilot air, for CPX m	etal interlinking	552287	VMPA-FB-EPLM-EU
	module				
Electrical interface f		1		F1/200	
	4 inputs/4 outputs,	Internal pilot air	Ducted exhaust	546989	VMPA-ASI-EPL-G-4E4A-Z
	according to spec. 2.1		air Silencer	546991	VMPA-ASI-EPL-GU-4E4A-Z
		External pilot air	Ducted exhaust	546991	VMPA-ASI-EPL-GO-4E4A-Z
			air	540900	VINIT A"A JI"LT L"L"4L4A"Z
			Silencer	546990	VMPA-ASI-EPL-EU-4E4A-Z
	8 inputs/8 outputs,	Internal pilot air	Ducted exhaust	546993	VMPA-ASI-EPL-G-8E8A-Z
	according to spec. 2.1		air		
			Silencer	546995	VMPA-ASI-EPL-GU-8E8A-Z
		External pilot air	Ducted exhaust	546992	VMPA-ASI-EPL-E-8E8A-Z
			air		
			Silencer	546994	VMPA-ASI-EPL-EU-8E8A-Z
	8 inputs/8 outputs,	Internal pilot air	Ducted exhaust	573184	VMPA-ASI-EPL-G-8E8A-CE
	according to spec. 3.0, extended		air	570404	
	addressing range	External pilot air	Silencer Ducted exhaust	573186	VMPA-ASI-EPL-GU-8E8A-CE
		External prior an	air	573183	VMPA-ASI-EPL-E-8E8A-CE
			Silencer	573185	VMPA-ASI-EPL-EU-8E8A-CE
			oneneer	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
Connection block fo	r AS-Interface				
	M12 socket, 5-pin			195704	CPX-AB-4-M12X2-5POL
	M8 socket, 3-pin			195706	CPX-AB-8-M8-3POL
	Spring-loaded terminals, 32-pin			195708	CPX-AB-8-KL-4POL
	Sub-D socket, 25-pin			525676	CPX-AB-1-SUB-BU-25POL
	Quick connector socket, 4-pin			525636	CPX-AB-4-HAR-4POL
Electrical interface f	or CPI				
	External pilot air, ducted exhaust air			546983	VMPA-CPI-EPL-E
	Internal pilot air, ducted exhaust air			546984	VMPA-CPI-EPL-G
	External pilot air, silencer	546985	VMPA-CPI-EPL-EU		
	Internal pilot air, silencer	546986	VMPA-CPI-EPL-GU		
Electrical interface f	or multi-pin plug connection				
Alia	External pilot air, ducted exhaust air			540893	VMPA1-MPM-EPL-E
	Internal pilot air, ducted exhaust air			540894	VMPA1-MPM-EPL-G
	External pilot air, silencer			540895	VMPA1-MPM-EPL-EU
	Internal pilot air, silencer			540896	VMPA1-MPM-EPL-GU

Accessories

Description With (mm) Part No. Type Electronics module For fieldbus connection 4 colis 20 \$37983 VMPA2-F8-EMS-4 Without separate circuit 4 colis 20 \$37984 VMPA2-F8-EMS-4 With separate circuit 4 colis 20 \$37984 VMPA2-F8-EMS-4 With separate circuit 4 colis 20 \$37984 VMPA2-F8-EMS-02-4 With separate circuit 4 colis 20 \$43334 VMPA2-F8-EMS-02-4 For multi-pin plug connection 2 colis 20 \$33786 VMPA2-F8-EMS-02-4 Modular (MFW) 2 colis 20 \$33787 VMPA2-F8-EMS-02-4 For multi-pin plug connection 2 colis 10 \$3788 VMPA2-F8-EMS-02-4 With separate circuit For proportional pressure regulator <th>Ordering data</th> <th></th> <th></th> <th></th> <th></th> <th></th>	Ordering data					
Electronics module For fieldbus connection S37993 VMPA2-FB-EMS-4 Without Separate circuit 4 colis 20 537994 VMPA2-FB-EMS-4 With separate circuit 4 colis 20 533984 VMPA2-FB-EMS-4 For fieldbus connection with extended diagnostic functor 8 colis 10 533301 VMPA2-FB-EMS-92-4 With separate circuit 4 colis 20 543332 VMPA2-FB-EMS-92-4 With separate circuit 4 colis 20 543332 VMPA2-FB-EMS-92-4 With separate circuit 4 colis 20 543333 VMPA2-FB-EMS-92-4 With separate circuit 4 colis 20 543333 VMPA2-FB-EMS-92-4 Modular (MPM) 2 colis 20 537985 VMPA2-FB-EMS-92-4 Modular (MPM) 2 colis 20 537986 VMPA2-FB-EMS-92-4 Modular (MPM) 2 colis 10 537986 VMPA2-FB-EMS-92-4 Modular (MPM) 2 colis 10 537986 VMPA2-FB-EMS-92-4 Electrical interlinking module for mouth-pin plug connection and AS-Interface	Description			Width	Part No.	Туре
Without separate circuit 4 coils 20 \$37983 VMPA2-RE-KMS-4 8 coils 10 \$33361 VMPA2-RE-KMS-4 8 coils 10 \$33361 VMPA2-RE-KMS-4 8 coils 10 \$33361 VMPA2-RE-KMS-4 8 coils 10 \$33361 VMPA2-RE-KMS-4 8 coils 10 \$33361 VMPA2-RE-KMS-02-4 8 coils 10 \$43332 VMPA2-RE-KMS-02-4 With separate circuit 4 coils 20 \$43332 VMPA2-RE-KMS-02-4 8 coils 10 \$43331 VMPA2-RE-KMS-02-4 With separate circuit 4 coils 20 \$43332 VMPA2-RE-KMS-02-4 8 coils 10 \$43333 VMPA2-RE-KMS-02-4 With separate circuit 4 coils 20 \$43332 VMPA2-RE-KMS-02-4 8 coils 10 \$537985 VMPA2-RE-KMS-02-4 Modular (MPM) 2 coils 20 \$37986 VMPA2-MPM-EMM-2 Modular (MPM) 2 coils 10 \$37987 VMPA2-MPM-EMM-8 Electrical module For proportional pressure regulator \$				[mm]		
B coils 10 533360 VMPA1-FB-EMS-8 With separate circuit 4 coils 20 537984 VMPA1-FB-EMG-8 For fieldbus connection with extended diagnostic function 8 coils 10 533360 VMPA1-FB-EMG-8 With separate circuit 4 coils 20 543332 VMPA1-FB-EMG-8 With separate circuit 4 coils 20 543333 VMPA1-FB-EMG-D2-8 With separate circuit 4 coils 20 543333 VMPA1-FB-EMG-D2-8 For multi-pin plug connection 8 coils 10 543333 VMPA1-FB-EMG-D2-8 Modular (MPM) 2 coils 20 537986 VMPA2-FB-EMG-D2-8 Modular (MPM) 2 coils 20 537986 VMPA2-FB-EMG-P3 Modular (MPM) 2 coils 20 537986 VMPA2-FB-EMG-P4 With separate circuit 4 coils 10 537986 VMPA2-FB-EMG-P4 With separate circuit For asub-base 54224 VMPA-FB-EMG-P1 54224 With separate circuit For asub-base 2 coils 20	Electronics module	For fieldbus connection				
With separate circuit 4 coils 8 coils 20 8 coils 537984 VMPA2-FB-EMG-4 8 coils For fieldbus connection with extended diagnostic function Without separate circuit 4 coils 20 \$43332 VMPA2-FB-EMS-D2-4 8 coils With separate circuit 4 coils 20 \$43332 VMPA2-FB-EMS-D2-4 8 coils With separate circuit 4 coils 20 \$43333 VMPA2-FB-EMS-D2-4 8 coils For multi-pin plug connection 2 coils 10 \$43333 VMPA2-FB-EMS-D2-8 8 coils For multi-pin plug connection 2 coils 20 \$37986 VMPA2-FB-EMS-D2-8 8 coils Moduar (MPM) 2 coils 20 \$37986 VMPA2-FB-EMS-D2-8 8 coils 8 coils 10 \$37987 VMPA2-FB-EMS-D2-8 8 coils \$4008 For multi-pin plug connection Plus \$10 \$37986 VMPA2-FB-EMS-D2-8 8 coils Feterical module For proportional pressure regulator \$42224 VMPA-FB-EMS-P1 Feterical supply plate For a sub-base \$41082 VMPA-FB-SP-7/8-V-SP0L Feterical interlinking module for multi-pin plug connection and AS-Interface \$20 \$37998 </td <td></td> <td>Without separate circuit</td> <td>4 coils</td> <td>20</td> <td>537983</td> <td>VMPA2-FB-EMS-4</td>		Without separate circuit	4 coils	20	537983	VMPA2-FB-EMS-4
B coils 10 533361 VMPA1-FB-EMG-8 For fieldbus connection with extended diagnostic function 4 coils 20 543332 VMPA2-FB-EMS-D2-4 With separate circuit 4 coils 20 543332 VMPA2-FB-EMS-D2-4 With separate circuit 4 coils 20 543333 VMPA2-FB-EMS-D2-4 With separate circuit 4 coils 20 543334 VMPA2-FB-EMG-D2-4 For multi-pin plug connection	AT I		8 coils	10	533360	VMPA1-FB-EMS-8
For fieldbus connection with extended diagnostic function 4 coils 20 543332 VMPA2-FB-EMS-D2-4 8 coils 10 543331 VMPA2-FB-EMS-D2-4 8 coils 10 543331 VMPA2-FB-EMS-D2-4 8 coils 20 543331 VMPA2-FB-EMS-D2-4 8 coils 10 543331 VMPA2-FB-EMG-D2-4 8 coils 20 543331 VMPA1-FB-EMG-D2-4 8 coils 10 543331 VMPA1-FB-EMG-D2-4 For multi-pin plug connection 8 coils 20 537986 VMPA2-FB-EMG-D2-4 8 coils 10 537987 VMPA-FB-EMS-D2-4 8 coils 10 537987 VMPA-FB-EMS-D2-4 8 coils 10 537987 VMPA-FB-EMS-FP 10 10 10 10 10 10 10 10 10 10 10 10 10 10		With separate circuit	4 coils	20	537984	VMPA2-FB-EMG-4
Without separate circuit 4 coils 20 543332 VMPA2-FB-EMS-D2-4 8 coils 10 543331 VMPA1-FB-EMS-D2-8 With separate circuit 4 coils 20 543333 VMPA1-FB-EMS-D2-8 With separate circuit 4 coils 10 543333 VMPA1-FB-EMS-D2-8 For multi-pin plug connection 8 coils 10 543333 VMPA1-FB-EMG-D2-4 Modular (MPM) 2 coils 20 537985 VMPA2-MPM-EMM-2 4 coils 10 537985 VMPA2-MPM-EMM-4 8 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-FB-EMG-P1 Electrical supply plate Plug connection M18, 3-pin 541082 VMPA-FB-SP-V Plug connection 7/8*, 5-pin 541082 VMPA-FB-SP-7/8-V-5POL 541083 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface 20 <td></td> <td></td> <td>8 coils</td> <td>10</td> <td>533361</td> <td>VMPA1-FB-EMG-8</td>			8 coils	10	533361	VMPA1-FB-EMG-8
Bit coils 10 543331 VMPA1-FB-EMS-D2-8 With separate circuit 4 coils 20 543334 VMPA2-FB-EMG-D2-4 8 coils 10 543334 VMPA2-FB-EMG-D2-4 8 For multi-pin plug connection 8 coils 10 5337985 VMPA2-FB-EMG-D2-8 Modular (MPM) 2 coils 20 537985 VMPA2-MPM-EMM-4 4 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537987 VMPA1-FB-EMG-P1 Vipeo For propritional pressure regulator 542224 VMPA-FB-SP-V Plug connection M18, 3-pin For a sub-base 541082 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8*, 4-pin 541082 VMPA-FB-SP-7/8-V-SPOL 541084 VMPA-FB-SP-7/8-V-SPOL For a sub-base For a sub-base </td <td></td> <td>5</td> <td>'n</td> <td></td> <td></td> <td></td>		5	'n			
With separate circuit 4 coils 8 coils 20 8 coils 543334 VMPA2-FB-EMG-D2-4 8 coils 10 For multi-pin plug connection 2 coils 10 543333 VMPA2-FB-EMG-D2-8 Modular (MPM) 2 coils 20 537985 VMPA2-MPM-EMM-2 4 coils 20 537986 VMPA2-MPM-EMM-4 4 coils 10 537986 VMPA2-MPM-EMM-4 4 coils 10 537986 VMPA2-MPM-EMM-4 8 coils 10 537986 VMPA1-MPM-EMM-4 8 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 Status 542224 VMPA1-MPM-EMM-8 Electrical supply plate Status 541082 VMPA-FB-SP-V Plug connection 7/8", 5-pin 541082 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8", 4-pin 541082 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface		Without separate circuit	4 coils	20	543332	VMPA2-FB-EMS-D2-4
B coils 10 543333 VMPA1-FB-EMG-D2-8 For multi-pin plug connection 2 coils 20 537985 VMPA2-MPM-EMM-4 Modular (MPM) 2 coils 20 537985 VMPA2-MPM-EMM-4 4 coils 20 537987 VMPA2-MPM-EMM-4 8 coils 10 537987 VMPA2-MPM-EMM-4 8 coils 10 537988 VMPA2-MPM-EMM-4 8 coils 10 537987 VMPA1-MPM-EMM-4 10 537988 VMPA1-MPM-EMM-8 10 537988 VMPA1-MPM-EMM-8 10 537988 VMPA1-MPM-EMM-8 10 537987 VMPA1-MPM-EMM-8 10 541082 VMPA-FB-SP-7/8-V-SPOL Plug connection M18, 3-pin 541083 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8", 4-pin 541083 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8", 4-pin 541084 VMPA2-MPM-EV-AB-2 10 537993 </td <td></td> <td></td> <td>8 coils</td> <td>10</td> <td>543331</td> <td>VMPA1-FB-EMS-D2-8</td>			8 coils	10	543331	VMPA1-FB-EMS-D2-8
For multi-pin plug connection 2 coils 20 537985 VMPA2-MPM-EMM-2 4 coils 20 537986 VMPA2-MPM-EMM-4 4 coils 20 537987 VMPA2-MPM-EMM-4 4 coils 10 537987 VMPA2-MPM-EMM-4 4 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-BPM-EMM-4 10 537988 VMPA1-BPM-EMM-8 9 <t< td=""><td></td><td>With separate circuit</td><td>4 coils</td><td>20</td><td>543334</td><td>VMPA2-FB-EMG-D2-4</td></t<>		With separate circuit	4 coils	20	543334	VMPA2-FB-EMG-D2-4
Modular (MPM) 2 coils 20 537985 VMPA2-MPM-EMM-2 4 coils 10 537986 VMPA2-MPM-EMM-4 4 coils 10 537986 VMPA2-MPM-EMM-4 4 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 Electrical module For proportional pressure regulator 542224 VMPA-FB-EMG-P1 Electrical supply plate For proportional pressure regulator 541082 VMPA-FB-SP-V Plug connection 7/8", 5-pin 541082 VMPA-FB-SP-V/ Plug connection 7/8", 4-pin 541082 VMPA-FB-SP-7/8-V-SPOL Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 20 537993 VMPA1-MPM-EV-AB-2 8 coils 10 537994 VMPA1-MPM-EV-AB-2 2 2 <			8 coils	10	543333	VMPA1-FB-EMG-D2-8
4 coils 20 537986 VMPA2-MPM-EMM-4 4 coils 10 537987 VMPA1.MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1.MPM-EMM-8 Electrical module S42224 VMPA-FB-EMG-P1 S42224 VMPA-FB-EMG-P1 Plug connection M18, 3-pin Plug connection 7/8°, 5-pin 541082 VMPA-FB-SP-V Plug connection 7/8°, 4-pin 541082 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8°, 4-pin 541083 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 for a sub-base 2 coils 10 537993 VMPA1-MPM-EV-AB-8 20 for a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537999 VMPA2-MPM-EV-AB-2 8 coils 10 537995 VMPA1-MPM-EV-AB-8 20 537999 VMPA1-MPM-EV-AB-4<						
4 coils 10 537987 VMPA1-MPM-EMM-4 8 coils 10 537988 VMPA1-MPM-EMM-8 Electrical module 5 5 5 5 Image: Sign of the state o		Modular (MPM)			537985	VMPA2-MPM-EMM-2
B coils 10 537988 VMPA1-MPM-EMM-8 For proportional pressure regulator 542224 VMPA-FB-EMG-P1 For proportional pressure regulator 542224 VMPA-FB-EMG-P1 For proportional pressure regulator 541082 VMPA-FB-SP-V Plug connection M18, 3-pin 541082 VMPA-FB-SP-V Plug connection 7/8", 5-pin 541083 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8", 4-pin 541084 VMPA-FB-SP-7/8-V-4POL Plug connection 7/8", 4-pin 541083 VMPA-FB-SP-7/8-V-4POL For a sub-base 2 coils 20 537999 VMPA2-MPM-EV-AB-2 10 537999 VMPA1-MPM-EV-AB-2 20 537991 VMPA1-MPM-EV-AB-2 10 537991 VMPA1-MPM-EV-AB-2 20 537995 VMPA1-MPM-EV-ABV-2 10 537995 VMPA1-MPM-EV-ABV-2 20 8 20 8 20 8 20 8 20 8 20 8 20 8 20 8 20 8 20 8			4 coils	20	537986	VMPA2-MPM-EMM-4
Electrical module Status propertional pressure regulator Status propertional pressure regulators Status propering propertional pressure regulators			4 coils	10	537987	VMPA1-MPM-EMM-4
For proportional pressure regulator \$42224 VMPA-FB-EMG-P1 Electrical supply plate Plug connection M18, 3-pin \$41082 VMPA-FB-SP-V Plug connection 7/8*, 5-pin Plug connection 7/8*, 5-pin \$41083 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8*, 4-pin \$41084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface \$41084 VMPA-FB-SP-7/8-V-4POL For a sub-base 2 coils 20 \$37989 VMPA2-MPM-EV-AB-2 A coils 10 \$37993 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37994 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37995 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37995 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37996 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37996 VMPA1-MPM-EV-AB-8 Electrical interlinking module for fieldbus connection and CPI 8 coils 10 \$37996 VMPA1-FB-EV-AB			8 coils	10	537988	VMPA1-MPM-EMM-8
For proportional pressure regulator \$42224 VMPA-FB-EMG-P1 Electrical supply plate Plug connection M18, 3-pin \$41082 VMPA-FB-SP-V Plug connection 7/8*, 5-pin Plug connection 7/8*, 5-pin \$41083 VMPA-FB-SP-7/8-V-SPOL Plug connection 7/8*, 4-pin \$41084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface \$41084 VMPA-FB-SP-7/8-V-4POL For a sub-base 2 coils 20 \$37989 VMPA2-MPM-EV-AB-2 A coils 10 \$37993 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37994 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37995 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37995 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37996 VMPA1-MPM-EV-AB-4 20 8 coils 10 \$37996 VMPA1-MPM-EV-AB-8 Electrical interlinking module for fieldbus connection and CPI 8 coils 10 \$37996 VMPA1-FB-EV-AB					·	
Electrical supply plate VMPA : FB : SP : V S41082 VMPA : FB : SP : V Plug connection 7/8*, 5: pin 541083 VMPA : FB : SP : 7/8 · V · SPOL Plug connection 7/8*, 5: pin 541083 VMPA : FB : SP : 7/8 · V · SPOL Plug connection 7/8*, 4: pin 541084 VMPA : FB : SP : 7/8 · V · 4POL Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base 2 coils 20 537989 VMPA : MPM - EV - AB - 2 For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 10 537994 VMPA : -MPM - EV - AB - 2 Rovis 1 of sarge so the sub-base 2 coils 20 537991 VMPA : -MPM - EV - AB - 2 Electrical interlinking module for fieldbus connection and CPI Electrical interlinking module for fieldbus connection and CPI	Electrical module					
Plug connection M18, 3-pin 541082 VMPA-FB-SP-V Plug connection 7/8", 5-pin 541083 VMPA-FB-SP-7/8-V-5POL Plug connection 7/8", 4-pin 541084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537993 VMPA1-MPM-EV-AB-2 A coils 10 537994 VMPA1-MPM-EV-AB-4 20 20 8 coils 10 537995 VMPA1-MPM-EV-AB-4 Electrical interlinking module for fieldbus connection and CPI Electrical interlinking module for fieldbus connection and CPI 537998 VMPA1-FB-EV-AB For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB Electrical interlinking module for fieldbus connection and CPI		For proportional pressure regulator			542224	VMPA-FB-EMG-P1
Plug connection M18, 3-pin 541082 VMPA-FB-SP-V Plug connection 7/8", 5-pin 541083 VMPA-FB-SP-7/8-V-5POL Plug connection 7/8", 4-pin 541084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537993 VMPA1-MPM-EV-AB-2 A coils 10 537994 VMPA1-MPM-EV-AB-4 20 20 8 coils 10 537995 VMPA1-MPM-EV-AB-4 Electrical interlinking module for fieldbus connection and CPI Electrical interlinking module for fieldbus connection and CPI 537998 VMPA1-FB-EV-AB For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB Electrical interlinking module for fieldbus connection and CPI	Electrical supply plat					
Plug connection 7/8", 5-pin 541083 VMPA-FB-SP-7/8-V-5POL Plug connection 7/8", 4-pin 541084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface 537989 VMPA-FB-SP-7/8-V-4POL Image: Straight of the sub-base 2 coils 20 537989 VMPA-FB-SP-7/8-V-4POL Image: Straight of the sub-base Image: Straight of the sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 Image: Straight of the sub-base Image: Straight of the sub-base Image: Straight of the sub-base 8 coils 10 537994 VMPA1-MPM-EV-AB-8 Image: Straight of the sub-base Image: Straight of the sub-base Image: Straight of the sub-base 10 537995 VMPA1-MPM-EV-ABV-2 Image: Straight of the sub-base Image: Straight of the sub-base<					5/1082	VMPA-FR-SP-V
Plug connection 7/8", 4-pin 541084 VMPA-FB-SP-7/8-V-4POL Electrical interlinking module for multi-pin plug connection and AS-Interface Image: Straight of the sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 Image: Straight of the sub-base 2 coils 20 537993 VMPA1-MPM-EV-AB-2 Image: Straight of the sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537994 VMPA1-MPM-EV-AB-8 Image: Straight of the sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537995 VMPA1-MPM-EV-AB-8 Image: Straight of the sub-base of t		r ug connection wild, 5 pm			541002	Viiii A-1 B-31 - V
Image: Second state of the sub-base Electrical interlinking module for multi-pin plug connection and AS-Interface For a sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 4 coils 10 537993 VMPA1-MPM-EV-AB-4 20 8 coils 10 537994 VMPA1-MPM-EV-AB-8 2 coils 20 537991 VMPA2-MPM-EV-AB-8 2 coils 10 537995 VMPA2-MPM-EV-AB-8 2 coils 20 537995 VMPA1-MPM-EV-AB-8 2 coils 10 537995 VMPA1-MPM-EV-ABV-2 4 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 10 537996 VMPA1-MPM-EV-ABV-8 10 537996 VMPA1-MPM-EV-ABV-8		Plug connection 7/8", 5-pin			541083	VMPA-FB-SP-7/8-V-5POL
For a sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 4 coils 10 537993 VMPA1-MPM-EV-AB-4 20 8 coils 10 537994 VMPA1-MPM-EV-AB-8 For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537991 VMPA2-MPM-EV-AB-8 8 coils 10 537995 VMPA1-MPM-EV-AB-8 8 coils 10 537995 VMPA1-MPM-EV-ABV-2 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8	and the second	Plug connection 7/8", 4-pin			541084	VMPA-FB-SP-7/8-V-4POL
For a sub-base 2 coils 20 537989 VMPA2-MPM-EV-AB-2 4 coils 10 537993 VMPA1-MPM-EV-AB-4 20 8 coils 10 537994 VMPA1-MPM-EV-AB-8 For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537991 VMPA2-MPM-EV-AB-8 8 coils 10 537995 VMPA1-MPM-EV-AB-8 8 coils 10 537995 VMPA1-MPM-EV-ABV-2 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8	Electrical interlinking	g module for multi-pin plug connection and AS-Interface				
Image: Second system 20 Image: Second system 8 coils 10 537994 VMPA1-MPM-EV-AB-8 Image: Second system 2 coils 20 537991 VMPA2-MPM-EV-AB-2 Image: Second system 2 coils 20 537995 VMPA1-MPM-EV-ABV-2 Image: Second system 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 Image: Second system 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Image: Second system 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Image: Second system 8 coils 10 537998 VMPA1-FB-EV-AB			2 coils	20	537989	VMPA2-MPM-EV-AB-2
8 coils 10 537994 VMPA1-MPM-EV-AB-8 For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537991 VMPA2-MPM-EV-ABV-2 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20 20 20 10 537998 VMPA1-FB-EV-AB			4 coils	10	537993	VMPA1-MPM-EV-AB-4
For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537991 VMPA2-MPM-EV-ABV-2 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-4 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20				20		
For a sub-base with pneumatic supply plate (on the left next to the sub-base) 2 coils 20 537991 VMPA2-MPM-EV-ABV-2 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20	\sim		8 coils	10	537994	VMPA1-MPM-EV-AB-8
next to the sub-base) 4 coils 10 537995 VMPA1-MPM-EV-ABV-4 20 8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20 20 20 20 537998 VMPA1-FB-EV-AB		For a sub-base with pneumatic supply plate (on the left	2 coils	20	537991	VMPA2-MPM-EV-ABV-2
8 coils 10 537996 VMPA1-MPM-EV-ABV-8 Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20			4 coils	10	537995	VMPA1-MPM-EV-ABV-4
Electrical interlinking module for fieldbus connection and CPI For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20				20		
For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20 20			8 coils	10	537996	VMPA1-MPM-EV-ABV-8
For sub-bases MPA size 1 and 2, and proportional pressure regulators 10 537998 VMPA1-FB-EV-AB 20 20	Electrical interlinking	g module for fieldbus connection and CPI				
20	/ Million		ure regulators	10	537998	VMPA1-FB-EV-AB
For a pneumatic supply plate 537000 V/MDA1 ED EV V				20		
		For a pneumatic supply plate			537999	VMPA1-FB-EV-V

Accessories

Description Pressure sensors			Part No.	Туре
Pressure sensors				Туре
			1	
	For monitoring the operating pressure in duct 1		541085	VMPA-FB-PS-1
	For monitoring the pressure in exhaust ducts 3 and 5		541086	VMPA-FB-PS-3/5
	For monitoring an external process pressure		541087	VMPA-FB-PS-P1
Cover				
<u></u>	Blanking plate for valve position ¹⁾ 5		533351	VMPA1-RP
			537962	VMPA2-RP
	Cover plate		559638	VMPA-P-RP
	Cover cap for manual override with coded cover cap, manua	al override non-detenting (x10)	540897	VMPA-HBT-B
$\overline{\mathbb{Q}}$	Cover cap for manual override, covered, manual override bl	ocked (x10)	540898	VMPA-HBV-B
	Cover cap for manual override, manual override detenting, without accessories (x10)	can be operated manually	8002234	VAMC-L1-CD
	Inscription label holder for an inscription label and a cover and the manual override (blocked) (x10)	for the signal status display	570818	ASLR-D-L1
Seal for manifold blo	ck			
		o duct separation	533359	VMPA1-DP
		uct 1 separated	533363	VMPA1-DP-P
	Du	uct 3/5 separated	533364	VMPA1-DP-RS
and a	Du	uct 1 and 3/5 separated	533365	VMPA1-DP-PRS
		o duct separation	533355	VMPA1-DPU
		uct 1 separated	533356	VMPA1-DPU-P
		uct 3/5 separated	533357	VMPA1-DPU-RS
		uct 1 and 3/5 separated	533358	VMPA1-DPU-PRS
Exhaust plate	1		T	
	Ducted exhaust air, with 10 mm push-in connector		533375	VMPA-AP
	Ducted exhaust air, with QS-3/8 connector		541629	VMPA-AP-3/8
	Flat plate silencer		533374	VMPA-APU
Supply plate (without	exhaust plate)		I	
	For ducted exhaust air		533354	VMPA1-FB-SP
	For flat plate silencer		533353	VMPA1-FB-SPU

1) A self-adhesive label is supplied.

FESTO

Accessories

•				
escription			Part No.	Туре
Multi-pin plug conn	ection, electrical			
<u> </u>	Cover without connecting cable for self-assembly		533198	VMPA-KMS-H
	PVC connecting cable for 8 solenoid coils	2.5 m	533195	VMPA-KMS1-8-2,5
		5 m	533196	VMPA-KMS1-8-5
$\nabla 0$	Iti-pin plug connection, electrical Cover without connecting cable for self-assembly PVC connecting cable for 8 solenoid coils 2.5 m 9 5 m 10 m 10 m PVC connecting cable for 24 solenoid coils 2.5 m 5 m 10 m PVC connecting cable for 24 solenoid coils, 2.5 m suitable for energy chains 5 m 10 m 10 m PUR connecting cable for 24 solenoid coils, 2.5 m suitable for energy chains 5 m 10 m 10 m PUR connecting cable for 24 solenoid coils, 2.5 m suitable for energy chains 5 m 10 m 0 m necting cable, AS-Interface connection 5 m Image: Straight plug connector, M12x1, 5-pin, A-coded 0.5 m Straight plug connector, M12x1, 4-pin, A-coded 0.5 m Modular system for connecting cables 0.5 m Image: Straight plug connector, 5-pin 0.5 m • Angled plug connector, 5-pin 0.5 m • Angled socket, 5-pin 0.5 m • Sm 3 m	533197	VMPA-KMS1-8-10	
	PVC connecting cable for 24 solenoid coils	2.5 m	533192	VMPA-KMS1-24-2,5
		5 m	533193	VMPA-KMS1-24-5
		10 m	533194	VMPA-KMS1-24-10
	PUR connecting cable for 8 solenoid coils,	2.5 m	533504	VMPA-KMS2-8-2,5-PUR
	suitable for energy chains	5 m	533505	VMPA-KMS2-8-5-PUR
		10 m	533506	VMPA-KMS2-8-10-PUR
	PUR connecting cable for 24 solenoid coils,	2.5 m	533501	VMPA-KMS2-24-2,5-PUR
	suitable for energy chains	5 m	533502	VMPA-KMS2-24-5-PUR
		10 m	533503	VMPA-KMS2-24-10-PUR
	• Straight plug connector, M12x1, 4-pin, A-coded			
	Modular system for connecting cables		-	→ Internet: nebu
connecting cable, C				
			540327	KVI-CP-3-WS-WD-0,25
	Angled socket, 5-pin		540328	KVI-CP-3-WS-WD-0,5
A.			540329	KVI-CP-3-WS-WD-2
-			540330	KVI-CP-3-WS-WD-5
		-	540331	KVI-CP-3-WS-WD-8
	• Straight plug connector, 5-pin	2 m	540332	KVI-CP-3-GS-GD-2
	Straight socket, 5-pin	5 m	540333	KVI-CP-3-GS-GD-5
a y		8 m	540334	KVI-CP-3-GS-GD-8

Accessories

Ordering data				
Description			Part No.	Туре
Push-in fitting for	manifold block, pneumatic interface, supply plate			
	Connecting thread M5 for tubing O.D.	3 mm (10 pieces)	153313	QSM-M5-3-I
		4 mm (10 pieces)	153315	QSM-M5-4-I
O.		6 mm (10 pieces)	153317	QSM-M5-6-I
		5/32" (1 piece)	130593	QSM-M5-5/32-I-U-M
		3/16" (1 piece)	183750	QSM-M5-3/16-I-U-M
		1/4" (50 pieces)	130591	QSM-M5-1/4-I-U-M
	Connecting thread M7 for tubing O.D.	4 mm (10 pieces)	153319	QSM-M7-4-I
		6 mm (10 pieces)	153321	QSM-M7-6-I
		3/16" (1 piece)	183739	QSM-M7-3/16-I-U-M
		1/4" (50 pieces)	183740	QSM-M7-1/4-I-U-M
	Connecting thread G ¹ /8 for tubing O.D.	6 mm (10 pieces)	186107	QS-G ¹ ⁄8-6-I
		8 mm (10 pieces)	186109	QS-G ¹ ⁄8-8-I
		1/4" (1 piece)	183741	QS-1/8-1/4-I-U-M
		5/16" (1 piece)	183742	QS-1/8-5/16-I-U-M
	Connecting thread G ¹ / ₄ for tubing O.D.	8 mm (10 pieces)	186110	QS-G ¹ /4-8-I
		10 mm (10 pieces)	186112	QS-G¼-10-I
		5/16" (1 piece)	183743	QS-1/4-5/16-I-U-M
		3/8" (1 piece)	183744	QS-1/4-3/8-I-U-M
<u> </u>	1		I	
Silencer				
	Connecting thread	M5 (1 piece)	165003	UC-M5
		M7 (1 piece)	161418	UC-M7
		G ¹ ⁄4 (1 piece)	165004	UC-1⁄4
<u>O</u>		G ¹ ⁄8 (1 piece)	161419	UC-1/8
	Push-in sleeve connection	3 mm (1 piece)	165005	UC-QS-3H
		4 mm (1 piece)	165006	UC-QS-4H
		6 mm (1 piece)	165007	UC-QS-6H
		8 mm (1 piece)	175611	UC-QS-8H
		10 mm (1 piece)	526475	UC-QS-10H
Blanking plug				
	Thread M5		3843	B-M5
	(10 pieces)			
\bigvee				
	Thread M7		174309	B-M7
	(10 pieces)			
(0)	G ¹ /8 thread		3568	B-1/8
\sim	(10 pieces)			
	Thread G ¹ /4		3569	B-1⁄4
	(10 pieces)			
Plug				
	Blanking plug for tubing O.D.	4 mm	153267	QSC-4H
at the second se	(10 pieces)	6 mm	153268	QSC-6H
*		8 mm	153269	QSC-8H
		10 mm	153270	QSC-10H
		3/16"	564785	QBC-3/16H-U
		1/4"	564786	QBC-1/4H-U
		5/16"	564787	QBC-5/16H-U
1		3/8"	564788	QBC-3/8H-U

Accessories

Ordering data				
Description			Part No.	Туре
Inscription labels				
	Inscription label holder for manifold block, transparent, for pap	er label	533362	VMPA1-ST-1-4
	Inscription label holder for manifold block, 4-fold, for IBS-6x10		544384	VMPA1-ST-2-4
	Inscription labels 6 x 10 in frame, 64 pieces		18576	IBS-6x10
	Inscription label holder for an inscription label and a cover for the manual override, 10 pieces			ASLR-D-L1
Mounting				
	For H-rail		526032	CPX-CPA-BG-NRH
	Mounting (for supply plate)		534416	VMPA-BG-RW
	Mounting (for proportional pressure regulator sub-base)		558844	VMPA-BG
÷				
User Documentation				
	MPA pneumatic components	German	534240	P.BE-MPA-DE
		English	534241	P.BE-MPA-EN
		French	534243	P.BE-MPA-FR
¥		Spanish	534242	P.BE-MPA-ES
		Italian	534244	P.BE-MPA-IT
	MPA electronic components description	German	562112	P.BE-MPA-Elektronik-DE
	(pneumatic modules, pressure sensors, proportional pressure	English	562113	P.BE-MPA-Elektronik-EN
	regulators, etc.)	French	562115	P.BE-MPA-Elektronik-FR
		Spanish	562114	P.BE-MPA-Elektronik-ES
		Italian	562116	P.BE-MPA-Elektronik-IT



Festo North America





1 Festo Canada Headquarters Festo Inc. 5300 Explorer Drive Mississauga, ON L4W 5G4 **2 Montréal** 5600, Trans-Canada Pointe-Claire, QC H9R 1B6

3 Québec City

2930, rue Watt#117 Québec, QC G1X 4G3



Festo Regional Contact Center

Canadian Customers

Commercial Support: Tel: 1 877 GO FESTO (1 877 463 3786) Fax: 1 877 FX FESTO (1 877 393 3786) Email: festo.canada@ca.festo.com

USA Customers

Commercial Support: Tel:1 800 99 FESTO (1 800 993 3786) Fax:1 800 96 FESTO (1 800 963 3786) Email: customer.service@us.festo.com

Subject to change

4 Festo United States Headquarters Festo Corporation 395 Moreland Road Hauppauge, NY 11788 5 Appleton North 922 Tower View Drive, Suite N Greenville, WI 54942

6 Chicago 85 W Algonquin - Suite 340 Arlington Heights, IL 60005 7 Detroit 1441 West Long Lake Road Troy, MI 48098

8 Silicon Valley 4935 Southfront Road, Suite F Livermore, CA 94550

Technical Support: Tel:1 866 GO FESTO (1 866 463 3786) Fax:1 877 FX FESTO(1 877 393 3786) Email: technical.support@ca.festo.com

Technical Support: Tel:1 866 GO FESTO (1 866 463 3786) Fax:1800 96 FESTO(1 800 963 3786) Email: product.support@us.festo.com

Internet: www.festo.com/us