

# **FESTO**



Key features



## Innovative

- Can be used for safe reversing of a hazardous movement (5/2-way solenoid valve)
- Can be used for safe venting (3/2-way solenoid valve function, not available as a variant for installation on a valve terminal)
- Purely mechanical solution as a press safety valve, without integrated diagnostics

# Versatile

- Control block can be selected as version for valve terminal VTSA/ VTSA-F
- Control block can be selected as individual pneumatic connection
- High pressure range of 3 ... 10 bar
- Flow rates of up to 1,050 l/min

# Reliable

- Sturdy and durable metal components
- Designed as a purely mechanical solution with regard to safety

## Easy to assemble

- Unit assembled and inspected, ready for installation
- Reduced outlay on selection, ordering, installation and commissioning
- Mounting via through-hole (with individual pneumatic connection)
- Mounting as vertical stacking elements on manifold sub-base of the valve terminal



Note

The control block with safety function VOFA must not be modified by the customer without authorisation as this invalidates the IFA approval

certificate.

The IFA certificate is linked to the checked safety function of the component.

Key features



### Description

The control block is designed for twochannel actuation of pneumatic drive components such as double-acting cylinders, and can be used to realise the following safety measures:

- Protection against unexpected start-up (EN 1037)
- Reversing hazardous movements, provided the reversing movement will not lead to any further hazards (5/2-way valve, single solenoid)
- Safe venting (with 3/2-way valve function in normally closed position)

The control attributes of the control block enable Performance Level e (up to Category 4, corresponds to the highest risk level) to be achieved for the safety measures. The Performance Level (PL) is a measure of the reliability of a safety function.

The control block has been developed and manufactured in accordance with the basic and proven safety principles of EN ISO 13849-1 and EN ISO 13849-2.

The requirements of EN ISO 13849-1 and EN ISO 13849-2 (e.g. CCF, DC) must be taken into consideration for implementation and operation of the component and for use in higher categories (2 to 4).

When using this product in machines or systems subject to specific C standards, the requirements specified in these standards must be observed.

The control block with safety function is designed for installation in machines and automation systems and must only be used in industrial applications (high-demand mode). The control block with safety function is suitable for use as a press safety valve to EN 692.

Further information and technical data in the Support Portal

→ Internet: safety-related guidelines

# Pneumatic/electrical interlinking

Function

The safety function is achieved through two-channel pneumatic interlinking of two 5/2-way single solenoid valves, width 26 mm, within the control block:

- Port 4 is only pressurised if both solenoid valves are in switching position.
- Port 2 is always pressurised if at least one of the two solenoid valves

is in normal position. The valve is reset via a mechanical spring.

The switching operation of the solenoid valves can be sensed by a proximity sensor on the solenoid valves (switching position sensing). This is done by comparing a logic operation of the control signal and the signal change of the proximity sensor

to check whether the piston spools of the solenoid valves achieve the expected position.

The piston spools of the solenoid valves are designed so that pneumatic short circuits between ports 2 and 4 are ruled out (freedom from overlap).

The two solenoid valves must be actuated via two separate channels to achieve the desired Category 4 (Performance Level e, to EN ISO 13849-1).

The valves used are always 5/2-way solenoid valves with switching position sensing.


3



Key features

#### Version

Decentralised individual connection variant, VOFA-L26-T52-...




With the decentralised individual connection variant, the electrical connection for the control block is established as an individual connection to ISO 15407-1. The pneumatic connection is also established as an individual connection. With this variant, the two 5/2-way solenoid valves are pneumatically interlinked via two channels by means of the individual sub-base.

The electrical connection for the solenoid valves is established separately via a standardised square plug to EN 175301-803, type C.

The inductive sensor for switching position sensing is electrically connected using a push-in connector M8x1 to EN 61076-2-104.

#### Decentralised individual connection variant, VOFA-L26-T32C-...



The function as a 3/2-way solenoid valve, normally closed, is intended for use for safe venting.




Note

The 3/2-way solenoid valve function is only available as a decentralised

individual connection variant (VOFA-L26-...).

## Version for valve terminal VTSA/VTSA-F, VOFA-B26-T52-...



With the version of the control block for valve terminal VTSA/VTSA-F, the valves are actuated separately from the valve terminal via an individual electrical connection.

The pneumatic connection is established via the valve terminal VTSA/VTSA-F.

With the variant for valve terminals, the two 5/2-way solenoid valves are pneumatically interlinked via two channels by means of an intermediate plate as vertical stacking element.

The electrical connection for the solenoid valves is established separately via a standardised square plug to EN 175301-803, type C. The inductive sensor for switching position sensing is electrically connected using a push-in connector M8x1 to EN 61076-2-104.




Note

The appropriate manifold sub-base VABV-S4- ..., which is required for integration into the valve terminal, is not part of the control block. It is

automatically allocated by the configurator on selection of the control block.


Key features





### **Equipment options**

Control block, version for valve terminal VTSA/VTSA-F, VOFA-B26-T52-...



Two 5/2-way solenoid valves, single solenoid, connected in series, interlinked via two channels

- Mechanical spring
- Switching position sensing via inductive sensors with PNP or NPN output

### Application:

- Protection against unexpected start-up to EN 1037
- Safe reversing
- Drives in manually loaded devices




Not

The 3/2-way solenoid valve function is not suitable for vertical stacking (on valve terminals).

### Control block as decentralised individual connection variant

VOFA-L26-T52-...



Two 5/2-way valves, single solenoid, connected in series, interlinked via two channels

- · Mechanical spring
- Switching position sensing via inductive sensors with PNP or NPN output

## Application:


- Protection against unexpected start-up to EN 1037
- Safe reversing (VOFA-L26-T52-...)
- Safe venting (VOFA-L26-T32C-..., 3/2-way solenoid valve function)
- Drives in manually loaded devices



The control block with safety function VOFA must not be modified by the customer without authorisation as this invalidates the IFA approval certificate.

The IFA certificate is linked to the checked safety function of the component.

VOFA-L26-T32C-...





Key features

#### Special features

Control block for valve terminal VTSA/VTSA-F

#### **Electrical connection**

- Flectrical connection to EN 175301-803, type C (square
- 3-pin sensor push-in connector M8

#### Pneumatic connection

- Via valve terminal VTSA/VTSA-F
- Pilot air supply via valve terminal
- Interlinked via two channels by way of vertical stacking as intermediate

Control block as decentralised individual connection variant

#### **Electrical connection**

- · Electrical connection to EN 175301-803, type C (square
- 3-pin sensor push-in connector M8

#### Pneumatic connection

- Individual pneumatic connection
- · Internal pilot air supply
- Interlinked via two channels by way of individual sub-base

### Applications

This control block is suitable for use as a press safety valve to EN 692.

This valve is a safety device in accordance with the Machinery Directive 2006/42/EC.

The 3/2 way solenoid valve version (VOFA-L26-T32C-...) is intended for safe venting.

The version for valve terminal VTSA/ VTSA-F and the version as individual connection variant VOFA-L26-T52-... are intended for safe reversing of a hazardous movement.

#### Valve terminal configurator

A valve terminal configurator is available to help you select a suitable valve terminal VTSA/VTSA-F. The control block VOFA for the valve terminal is ordered using this valve terminal configurator. This makes it much easier to order the right product.

The valve terminals are fully assembled according to your order specification and are individually checked. This reduces assembly and installation time to a minimum.

You can order a control block VOFA for the valve terminal VTSA using the order code:

Ordering system for VTSA → Internet: vtsa

→ Internet: www.festo.com


You can order a control block VOFA for the valve terminal VTSA-F using the order code:

Ordering system for VTSA-F

→ Internet: vtsa-f



Key features



<sup>1)</sup> The symbol represents a valve with a proximity sensor with a switching output signal, in the illustration an N/O contact. In accordance with ISO 1219-1, this symbol applies to both N/O contacts and N/C contacts. The switching element function of all sensors used here is an N/C contact.

- i ■ - Note
- The 2x 5/2-way solenoid valves each have their own electrical connection.
- The 2x 5/2-way solenoid valves are pneumatically interlinked via two channels by means of an individual sub-base/ intermediate plate.
- The output of the interlinked 2x 5/2-way solenoid valves is only switched if both valves are in switching position.



Safety-related characteristics								
Control block		VOFA-L26-T52	VOFA-L26-T32C	VOFA-B26-T52 on valve terminal				
Conforms to		EN 13849-1						
Safety function		Security against manipulation, prot	Security against manipulation, protection against unexpected start-up					
		Reversing of a movement Exhausting		Reversing of a movement				
Performance Level (PL)		Security against manipulation, prot	ection against unexpected start-up (ı	up to Category 4, Performance Level e)				
		Reversing of a movement (up to	Exhausting (up to Category 4,	Reversing of a movement (up to				
		Category 4, Performance Level e)	Category 4, Performance Level e) Performance Level e) Category 4, Performa					
Note on forced checking procedu	re	Switching frequency at least 1/week						
Certificate issuing authority		IFA 1004008	IFA 1204006	IFA 1004008				
CE marking		To EU Machinery Directive						
(see declaration of conformity)		To EU EMC Directive <sup>1)</sup>						
Max. positive test pulse	[µs]	1,000						
with 0 signal <sup>2)</sup>								
Max. negative test pulse	[µs]	800						
with 1 signal <sup>2)</sup>								
Shock resistance <sup>2)</sup>		Shock test with severity level 2, to EN 60068-2-27						
Vibration resistance <sup>2)</sup>		Transport application test with severity level 2, to EN 60068-2-6						

For information about the applicability of the component see the manufacturer's EC declaration of conformity at: www.festo.com/sp → User documentation.
 If the component is subject to restrictions on usage in residential, office or commercial environments or small businesses, further measures to reduce the emitted interference may be necessary.

 Please also note the safety-related applications and safety technology on the Support Portal

General technical data								
Control block		VOFA-L26-T52	VOFA-B26-T52 on valve terminal					
Design		Piston spool valve						
Standard nominal flow rate	[l/min]	950	830					
Standard flow rate	[l/min]	-	2,650	-				
Exhaust from 6 0 bar1)								
Standard flow rate	[l/min]	-	1,050	-				
Exhaust 6 0 bar in a fault								
situation <sup>1),2)</sup>								
Reset method		Mechanical spring						
Sealing principle		Soft						
Exhaust function		With flow control						
Actuation type		Electric						
Non-overlapping		Yes						
Type of control		Piloted						
Direction of flow		Non-reversible						
Exhaust function		With flow control						
Suitability for vacuum		-						
Pilot air supply		Internal Via valve terminal						
Type of mounting		Via through-hole, on manifold sub-base						
Mounting position		Any						
Manual override		-						
Valve signal status display		Via accessories						
Pneumatic connections								
Supply	1	G1/4	G1/4	Via the manifold sub-base of the				
Exhaust	3/5	G1/4	G1/4 (only 3)	valve terminal				
Working lines	2/4	G1/4	G1/4 (only 2)					
Pilot air supply	14	-	-					
Pressure gauge		G1/4	_	G <sup>1</sup> / <sub>4</sub>				

<sup>1)</sup> Measured in the exhaust direction (2->3), P= 6 bar measured with respect to atmosphere using a silencer UO-1/4.

<sup>2)</sup> A fault situation means: one of the two directional control valves does not completely switch back.

# **Control block VOFA with safety function**Technical data



Operating and environmental con	nditions						
Control block		VOFA-L26-T52	VOFA-L26-T32C	VOFA-B26-T52 on valve terminal			
Operating medium		Compressed air to ISO 8573-1	:2010 [7:4:4]				
Pilot medium		Compressed air to ISO 8573-1:2010 [7:4:4]					
Note about the operating/pilot medium		Lubricated operation possible (required during subsequent operation)					
Operating pressure	[bar]	3 10 0 10					
Operating pressure for valve	[bar]	-		3 10			
terminal with internal pilot air							
supply							
Pilot pressure	[bar]	3 10					
Noise level LpA	[dB(A)]	85					
Ambient temperature	[°C]	-5 +50					
Temperature of medium	[°C]	-5 +50					
Corrosion resistance class CRC		0					

Electrical data – Control b	lock							
Control block			VOFA-L26-T52	VOFA-L26-T32C	VOFA-B26-T52 on valve termin			
Electrical connection			Plug to EN 175301-803, type	Plug to EN 175301-803, type C, without protective earth conductor				
Nominal operating voltage		[V DC]	24					
Permissible voltage fluctua	ations	[%]	-15/+10					
Surge resistance		[kV]	2.5					
Degree of contamination	Degree of contamination							
Power consumption		[W]	1.8					
Max. magnetic disruption	field	[mT]	60					
Piston position sensing			Normal position via sensor					
Switching position display	Switching position display			With accessories				
Duty cycle [%]			100					
Protection class to EN 605	29		IP65, NEMA 4 (for all types of signal transmission in assembled state)					
Protection against direct a	nd indire	ct contact	PELV (Protective Extra-Low Voltage)					
			Protected to EN 60950/IEC 950					
Valve switching time On [ms]		22	24	22				
	Off [ms]		56	54	59			
Valve sensor switching	Valve sensor switching On [ms]		60	58	60			
time <sup>1)</sup>	Off	[ms]	11 11 11					

<sup>1)</sup> Valve sensor switching time off: period of time from coil being energised to sensor being switched off when using a PNP sensor. Valve sensor switching time on: period of time from coil being de-energised to 0-L edge at the sensor when using a PNP sensor.



With a duty cycle of 100%, the control block must be de-energised once a week.

# **Control block VOFA with safety function** Technical data




Electrical data – Sensor (to EN-6	0947-5-2)	
Electrical connection		Cable, 3-wire
		Plug M8x1, 3-pin
Cable length	[m]	2.5
Switching output		PNP or NPN
Switching element function		N/C contact
Signal status display		Yellow LED
Operating voltage range	[V DC]	10 30
Residual ripple	[%]	±10
Sensor idle current	[mA]	Max. 10
Max. output current	[mA]	200
Voltage drop	[V]	Max. 2
Max. switching frequency	[Hz]	5,000
Protection against short circuit		Pulsed
Protection against polarity reversal for sensor		For all electrical connections
Measuring principle		Inductive

Materials					
Sub-base/manifold sub-base	Wrought aluminium alloy				
Housing	Die-cast aluminium, PA				
Seals	NBR, FPM, HNBR				
Screws	Galvanised steel				
Sensor housing	High-alloy stainless steel				
Sensor cable sheath	PUR				
Note on materials	RoHS-compliant				


**FESTO** 


Technical data





Technical data







Ordering data – Control block

Ordering data		1			1		
	Valve function	Code	Switching	Width	Weight	Part No.	Type
			output				
				[mm]	[g]		
Control block, version	for valve terminal VTSA/VTSA-F						
	5/2-way valve, single solenoid, mechanical	SP <sup>2)</sup>	PNP	53	1,112	_ 1)	VOFA-B26-T52-M-1C1-APP
	spring return, with switching position sens-						
	ing via inductive sensor and 3-pin sensor						
	push-in connector M8, mounted on inter-	SN <sup>2)</sup>	NPN	53	1,112	_ 1)	VOFA-B26-T52-M-1C1-ANP
	mediate plate for pneumatic interlinking						
Control block, as dece	entralised individual connection variant						
المحق	5/2-way valve, single solenoid, mechanical	_	PNP	65	1,138	569819	VOFA-L26-T52-M-G14-1C1-APP
	spring return, with switching position sens-						
	ing via inductive sensor and 3-pin sensor						
	push-in connector M8, mounted on	_	NPN	65	1,138	569820	VOFA-L26-T52-M-G14-1C1-ANP
	individual sub-base			05	1,130	307020	101A 220 132 III 014 101 AIII
0000							
	2/2 way also machanical ansing vatura		PNP	<b>( F</b>	1 124	F74011	VOTA 127 T225 M C47 454 ADD
	3/2-way valve, mechanical spring return,	-	PINP	65	1,134	574011	VOFA-L26-T32C-M-G14-1C1-APP
	with switching position sensing via						
	inductive sensor and 3-pin sensor push-in						
	connector M8, mounted on individual	-	NPN	65	1,134	574012	VOFA-L26-T32C-M-G14-1C1-ANP
	sub-base						

- 1) The control block with safety function can only be ordered via the valve terminal configurator and therefore does not have a separate part number.
- 2) Code letter within the order code for a valve terminal configuration.



Silencer – Loss of safety function (VOFA -L26-T32C-...)

The addition of commercially available silencers can cause errors ranging from a reduction in exhaust performance to complete failure of the safety function.

In order to avoid such errors, proceed as follows:

- Use a silencer of type UO-1/4 or equivalent type
- Do not use sintered metal silencers
- When using a silencer, make sure the exhaust is unobstructed (exhaust outlet should have a minimum axial clearance of 15 mm)
- The silencer and exhaust (port 3) must not be blocked



## Sensors

The sensors contained in the valves must not be replaced by the customer. Incorrect assembly can result in malfunctions or damage to the valve.

Please contact Festo in the event of a malfunction.

# **Control block VOFA with safety function**Accessories

**FESTO** 

Ordering data					
	Description		Part No.	Туре	
Plug socket for elec	ctrical connection of individual valves				
	Angled socket, 3-pin, screw terminal, cable connector				MSSD-EB
			M12	539712	MSSD-EB-M12
			IVIIZ	559/12	WI33D-ED-WI12
Illuminating seal fo	or plug pattern to EN 175301-803, type C		151717	Technical data → Internet: meb-ld	
	For plug socket MSSD				MEB-LD-12-24DC
Connecting cable for	or electrical connection of individual valves				
23	Angled socket, 3-pin, with signal status display via LED		2.5 m	151688	KMEB-1-24-2,5-LED
			5 m	151689	KMEB-1-24-5-LED
			10 m	193457	KMEB-1-24-10-LED
<u> </u>			10 111	255157	100 1 2 7 10 125
Connecting cable for	or electrical connection of sensors for switching position sensing				
	Straight socket, 3-pin, plug M8		2.5 m	541333	NEBU-M8G3-K-2,5-LE3
	Open end, 3-wire				·
	Straight socket, 3-pin, plug M8		5 m	541334	NEBU-M8G3-K-5-LE3
	Open end, 3-wire				
	Angled socket, rotatable, 3-pin, plug M8		2.5 m	8001660	NEBU-M8R3-K-2.5-LE3
	Open end, 3-wire				
	Angled socket, rotatable, 3-pin, plug M8		5 m	8001661	NEBU-M8R3-K-5-LE3
	Open end, 3-wire		2.5		NEBU MOSO K A T MOS (
	Straight socket, straight plug, 3-pin, 4-pin plug M8		2.5 m	554037	NEBU-M8G3-K-2,5-M8G4
	Modular system for connecting cables		_	-	NEBU
					→ Internet: nebu
Silencer	Connecting thread		C1/ <sub>2</sub>	107504	UO-1/4
	Connecting thread		G1/4	197584	UU- <del>1</del> /4
-					
Push-in fitting				T	
	Connecting thread G <sup>1</sup> / <sub>4</sub> for tubing O.D.	12 mm	10 pieces	186350	QS-G <sup>1</sup> / <sub>4</sub> -12
		10 mm	10 pieces	186101	QS-G <sup>1</sup> / <sub>4</sub> -10
		8 mm	10 pieces	186099	QS-G <sup>1</sup> / <sub>4</sub> -8
Blanking plug					
	Connecting thread	G <sup>1</sup> / <sub>4</sub>	10 pieces	3569	B-1/4
			10 pieces		= 17

# **Festo North America**





1 Festo Canada Headquarters Festo Inc. 5300 Explorer Drive Mississauga, ON L4W 5G4

**2** Montréal 5600, Trans-Canada Pointe-Claire, QC H9R 1B6

**3** Québec City 2930, rue Watt#117 Québec, QC G1X 4G3



4 Festo United States
Headquarters
Festo Corporation
395 Moreland Road
Hauppauge, NY
11788

# 5 Appleton North 922 Tower View Drive, Suite N Greenville, WI 54942

# 6 Chicago 85 W Algonquin - Suite 340 Arlington Heights, IL 60005

**7 Detroit** 1441 West Long Lake Road Troy, MI 48098

# 8 Silicon Valley 4935 Southfront Road, Suite F Livermore, CA 94550

## **Festo Regional Contact Center**

## **Canadian Customers**

Commercial Support: Tel: 1 877 GO FESTO (1 877 463 3786) Fax: 1 877 FX FESTO (1 877 393 3786) Email: festo.canada@ca.festo.com

## **USA Customers**

Commercial Support: Tel:1 800 99 FESTO (1 800 993 3786) Fax:1 800 96 FESTO (1 800 963 3786) Email: customer.service@us.festo.com Technical Support: Tel:1 866 GO FESTO (1 866 463 3786) Fax:1 877 FX FESTO(1 877 393 3786) Email: technical.support@ca.festo.com

Technical Support: Tel:1 866 GO FESTO (1 866 463 3786) Fax:1800 96 FESTO(1 800 963 3786) Email: product.support@us.festo.com

Subject to change Internet: www.festo.com/us

U